




Model SL-520

Parts and Operations Manual



Hoist Serial Number: _____

TABLE OF CONTENTS

I. INTRODUCTION

Letter to Customer
Warranty Statement
Safety Suggestions
Decal Assembly and Descriptions
Serial Number Locations

II. INSTALLATION

Initial Inspection
Hoist Installation
Controls Installation
Hydraulic Tank Installation
P.T.O. Selection
Pump Installation
Start Up Procedure
300 Series Sub-Frame Dimensions
400 Series Sub-Frame Dimensions
Stabilizer Installation (Optional)
Accessory Installation
 Rear Bumper Assembly
 Rear Bumper Assembly, w/ Extension
 Bumper Assembly, Folding
 Bumper Assembly, Drop Down
 Cab Guard Assembly
 Fender Assembly, Tandem Axle
 Rear Light Bar Assembly
 Roller & Roller Mount
 Toolbox Assembly

III. OPERATION

Loading a Container
Dumping a Container
Placing a Container on the Ground
Operating the Stabilizer
Changing Hook Heights
 Adjusting Jib (Optional)
Rear Roller Spacing Adjustment

IV. MAINTENANCE

Weekly Service (50 Operations)
Monthly Service (200 Operations)
Yearly Service
Lubrication Diagram
Hydraulic Oil Specifications
Hydraulic Filter Interchange
Mast Lock (Safety Latch) Inspection &
 Adjustment Instructions
Jib Lockout Valve Inspection & Adjustment
 Instructions
Pressure Check Instructions
Outer Tube Clamp Assembly Inspection
 Instructions

V. PARTS LIST

Base Assembly w/ Adj. Jib
Base Assembly w/ Fixed Jib
Outer Tube Sub-Assembly
Main Frame Sub-Assembly
Pivot Lock Sub-Assembly
Adjustable Jib Sub-Assembly
Fixed Jib Sub-Assembly
Pivot Joint Sub-Assembly
Hoist Installation Kit Assembly
Hydraulic Sub-Assembly – Pump Circuit
Hyd. Sub-Ass'y – Base Cylinder Circuit
Hyd. Sub-Ass'y – Chassis-Tank Circuit

VI. OPTIONS

Air Circuit, 2 Section
Air Circuit, 3-Section
Air Control Assembly, 2-Section
Air Control Assembly, 3-Section
Manual Control Assembly, 2-Section
Manual Control Assembly, 3-Section
Stabilizer Final Assembly
Hyd. Sub-Assembly – Stabilizer Circuit

INTRODUCTION

SWAPLOADER U.S.A., LTD.

TO THE CUSTOMER

Your new SwapLoader Hoist was carefully designed and manufactured to give years of dependable service. To keep it operating efficiently, read the instructions in this manual thoroughly. It contains detailed descriptions and instructions for the efficient operation and maintenance of your SwapLoader. Each section is clearly identified so you can easily find the information that you need. Read the Table of Contents to learn where each section is located. All instructions are recommended procedures only.



Throughout this manual you will come across "**Dangers**," "**Warnings**," or "**Cautions**" which will be carried out in bold type and preceded by the symbol as indicated to the left. Be certain to carefully read the message that follows to avoid the possibility of personal injury or machine damage.

Record your SwapLoader Hoist serial number in the appropriate space provided on the title page. Your SwapLoader dealer needs this information to give you prompt, efficient service when you order parts. It pays to rely on an authorized SwapLoader Distributor for your service needs. For the location of the Distributor nearest you, contact SwapLoader.

NOTE: It is SwapLoader's policy to constantly strive to improve SwapLoader products. The information, specifications, and illustrations in this publication are based on the information in effect at the time of approval for printing and publishing. SwapLoader therefore reserves the right to make changes in design and improvements whenever it is believed the efficiency of the unit will be improved without incurring any obligations to incorporate such improvements in any unit which has been shipped or is in service. It is recommended that users contact an authorized SwapLoader Distributor for the latest revisions.

SWAPLOADER, U.S.A., LTD.
1800 N.E. BROADWAY, DES MOINES, IOWA 50313

LIMITED WARRANTY STATEMENT

Effective September 1, 2009

SwapLoader U.S.A., Ltd., (SwapLoader), warrants to the original purchaser of any new SwapLoader product sold by an authorized SwapLoader distributor or service center, that such products are free of defects in material and workmanship. All SwapLoader products with an original factory invoice date of September 1, 2009 or later qualify for warranty as defined in this Limited Warranty Statement.

- Repair or replacement of parts on SwapLoader products are covered under warranty for forty-eight (48) months from date of Retail Sale by an authorized SwapLoader Distributor or service center, subject to any applicable federal, state or local taxes, and not to extend beyond sixty (60) months from the original factory invoice date. SwapLoader will, at its discretion, either repair the defective parts or replace them with equivalent parts, subject to the conditions below.
- Labor charges authorized by the SwapLoader Warranty Department are covered under warranty for a period of twelve (12) months from the date of Retail Sale by an authorized SwapLoader Distributor or service center, and not to extend beyond twenty-four (24) months labor from the original factory invoice date.
- Warranty Registration Card must be returned within 15 days of Retail Sale of SwapLoader hoist to SwapLoader, Des Moines, Iowa. If unit has not been registered, then the warranty start date will revert to the original factory invoice date. Warranty Registration is the ultimate responsibility of the owner and may be accomplished by the completion and return of the product registration form included in the SwapLoader hoist manual. If the owner is not sure that product registration is completed, then SwapLoader encourages them to contact us at 888-767-8000 to confirm.
- Defective parts must be reported to SwapLoader within 30 days of discovery on a SwapLoader warranty claim report form. A Return Goods Authorization (RGA) number must be issued to the claiming party prior to the return of any defective part to be considered for warranty.
- Warranty service must be performed by a distributor or service center authorized by SwapLoader to sell and/or service SwapLoader products, which will use only new or remanufactured parts or components furnished by SwapLoader U.S.A., Ltd. SwapLoader will invoice the distributor or authorized service center for the replacement parts and freight. Upon completion of the repair any defective parts to be returned for warranty consideration must be returned freight prepaid with a copy of the SwapLoader issued RGA form and a copy of the completed warranty claim report form. Upon evaluation of the returned parts, once warranty is approved, credit will be issued to the appropriate account for the approved warranty costs which may include parts, labor, and/or freight.
- The warranty covers only defective material and workmanship. It does not cover depreciation or damage caused by normal wear and tear, accident, mishap, untrained operators, or improper or unintended use. The owner has the obligation of performing routine care and maintenance duties as stated in SwapLoader's written instructions, recommendations, and specifications. Any damage resulting from owner/ operator failure to perform such duties shall void the coverage of this warranty. The cost of labor and supplies associated with routine maintenance will be paid by the owner.
- In no event will SwapLoader, the SwapLoader distributor or any company affiliated with SwapLoader be liable for business interruptions, costs of delay, or for any special, indirect, incidental or consequential costs or damages. Such costs may include, but are not limited to loss of time, loss of revenue, loss of use, wages, salaries, commissions, lodging, meals, towing, hydraulic fluid, travel, mileage, or any other incidental costs.
- SwapLoader is not responsible for the removal or replacement of accessories (fenders, toolbox, etc.).
- Warranty shall not apply if the equipment is operated at capacities in excess of factory recommendations.
- Warranty is expressly void if the seal on the main relief control valve has been broken.
- SwapLoader will ship the replacement part by the most economical, yet expedient means possible. Expedited freight delivery will be at the expense of the owner.
- Warranty is expressly void if serial number plate or stamping is tampered with.


IT IS EXPRESSLY UNDERSTOOD AND AGREED THAT THERE ARE NO WARRANTIES MADE BY THE MANUFACTURER OR ITS AGENTS, REPRESENTATIVES OR DISTRIBUTORS, EITHER EXPRESSED, IMPLIED, OR IMPLIED BY LAW, EXCEPT THOSE EXPRESSLY STATED ABOVE IN THIS STANDARD LIMITED WARRANTY AGAINST DEFECTS IN MATERIAL AND WORKMANSHIP. THE MANUFACTURER AND ITS AGENTS, REPRESENTATIVES AND DISTRIBUTORS SPECIFICALLY DISCLAIM ANY IMPLIED WARRANTY OR MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE.

SWL Warranty 083109



SAFETY SUGGESTIONS


1. Do not operate or service this equipment until you have been properly trained and instructed in its use and have read the operation and service manual.



2. Do not operate this equipment on uneven ground.




3. Do not drive with the hoist in the dump position or with the hook to the rear.



4. Do not exceed 1,500 Engine RPM when operating the Power Take Off (P.T.O.). Never leave the P.T.O. in gear while transporting.
5. The hoist must be used with containers that properly fit the hook and rear holddowns. The container specifications must match the hoist specifications.
6. Keep the containers and hoist in good working order. **DO NOT** use if repairs are needed. Perform periodic inspections and maintenance as required by the maintenance section of the operator's manual.

7. Make sure work area is clear of people and obstacles prior to dumping or unloading containers. SwapLoader strongly recommends that a back up alarm be installed on the truck chassis. The operation of the hook hoist is that the truck is backed up to the body to pick it up and so there is a potential pinch point between the body and the hook.




8. Any container, which is on the hoist, **MUST** be unloaded prior to performing any repairs or maintenance to the hoist. Also, **DO NOT** allow any person to work on or be under the hoist in a raised position without first installing adequate safety blocks to eliminate all possibility of the hoist accidentally lowering. SwapLoader strongly recommends that if possible the container should be dismantled from the hoist prior to performing any maintenance to the hoist.



9. It is the responsibility of the owner and/or installer to insure that any additional safety devices required by state or local codes are installed on the SwapLoader Hoist and/or Truck Chassis.


10. Keep away from overhead power lines. Serious injury or death can result from contact with electrical lines. Use care when operating hoist near electrical lines to avoid contact.



11. Avoid contact with high-pressure fluids. Escaping fluid under pressure can penetrate the skin causing serious injury. Avoid hazardous conditions by relieving pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure. Search for leaks with a piece of cardboard, while protecting hands and body from the high-pressure fluids.
















12. It is the responsibility of the owner to provide proper maintenance of the Safety Decals. Regular inspection and replacing of Safety Decals that have any fading or damage which would impair their function should be done (See the illustration on the following page for location of Safety Decals).



ITEM	QTY	P/N	DESCRIPTION
1	2	90P07	OPERATION & SERVICE MANUAL
2	2	90P08	HOIST-BODY SPECIFICATIONS
3	ONE	90P09	HYDRAULIC OIL SPECIFICATIONS
4	ONE	90P10	HYDRAULIC OIL FLAMMABLE
5	2	90P11	HOIST FALLING
6	ONE	90P12	LEVER CONTROL
7	ONE	90P13	SAFETY INSTRUCTIONS
8	2	90P14	SWAPLOADER - JIB
9	ONE	90P18	RELIEF VALVE
10	4	91P14	SL-520
11	ONE	90P78	HIGH-PRESSURE FLUID
12	2	91P06	LUBRICATION POINTS
13	2	90P94	ADJUSTABLE JIB OPERATION

The following is a list of all the SwapLoader Safety Decals, and their part numbers. Please use when reordering replacement decals.

90P07 – OPERATIONS & SERVICE MANUAL	
90P08 – HOIST-BODY SPECIFICATIONS	
90P09 – HYDRAULIC OIL SPECIFICATIONS	
90P10 – HYDRAULIC OIL FLAMMABLE	
90P11 – HOIST FALLING	
90P12 – LEVER CONTROL	


<p>90P13 – SWAPLOADER SAFETY INSTRUCTIONS</p>	
<p>90P14 – SWAPLOADER - JIB</p>	
<p>90P18 – RELIEF VALVE</p>	
<p>91P14 – SL-520</p>	
<p>90P78 – HIGH-PRESSURE FLUID</p>	
<p>91P06 – LUBRICATION POINTS</p>	
<p>90P94 – ADJUSTABLE JIB OPERATION</p>	

Serial Number Locations on a SwapLoader Hoist



Serial Number Tag is located at the front driver side of the hoist (gray arrow on first picture).

The Serial Number is stamped into the frame of the hoist on the top of the “inner rail” shown at the rear of the hoist (black arrow on first picture). An example of a 6-character serial number is shown in the second picture.



INSTALLATION

INITIAL INSPECTION

When the hoist is installed and ready for delivery, it is your responsibility to fill out and submit the following Pre-Delivery Inspection and the Warranty Registration Form to SwapLoader U.S.A., Ltd. sales@swaploader.net or fax to (515) 313-4426 within 15 days of installation to register warranty.

SWAPLOADER
U.S.A. LTD.
"Proud in Quality"

SWL-005 SWAPLOADER 1/13

PRE-DELIVERY CHECK LIST

INSPECTOR'S INFORMATION

Inspected By: _____ Signature: _____
Distributor: _____ Date Installed: _____
Customer: _____ Date Inspected: _____

I. COMPONENT INFORMATION

Hoist Model: _____
Hoist Serial No.: _____
Chassis VIN: _____
Chassis Make & Model: _____
Chassis GVWR: _____
Chassis CAJCT: _____
After Frame: _____

Distance from rear of cab to the
centerline of rear axle/hook:
Distance from centerline of rear
axle/hook to rear of hoist:

PTO Make: _____
PTO Model: _____
PTO Serial No.: _____
PTO % of Engine RPM: _____

Hyd. Pump Make: _____
Hyd. Pump Model: _____
Hyd. Pump Serial No.: _____

II. INSTALLATION TO CHASSIS

Were there any problems installing the hoist to the truck chassis? ☐ YES ☐ NO

If yes, please describe: _____

☐ All bolts checked for proper tightness.

☐ Please include photos of the hoist installed on the truck chassis.
Be sure to include at least one photo from each side of the chassis/hoist.

SWAPLOADER U.S.A., LTD.
1800 N.E. BROADWAY AVENUE
DES MOINES, IA 50313

WARRANTY REGISTRATION CARD

Model: _____ Serial No.: _____

ACCOUNT ON VEHICLE:

Manufacturer: _____
Model: _____
Year: _____
Wheel Base: _____
Chassis Serial #: _____
PTO Type: _____
PTO Ratio: _____

DISTRIBUTOR:

Name (print): _____
Address: _____
City, State, Zip: _____

The unit has been checked and serviced according to the Pre-delivery inspection report. The proper mechanical operation of the unit as described in the written operation instructions provided by SwapLoader U.S.A., Ltd. has been discussed with the customer.

Customer Name: _____ (please print) Date Installed: _____
Address: _____ (please print) Date Inspected: _____
City, State, Zip: _____ (please print)

Customer Phone Number: _____ (required)

Customer Signature: _____ Distributor Signature: _____

Type of Application Swap loader hoist will be used in:

☐ Waste Industry ☐ Landscaping ☐ Public Works
☐ Construction ☐ Truck/Machinery ☐ General Construction
☐ Recycling ☐ Roadwork ☐ Other

SWL-005

III. CONTROLS

☐ On slide swing to center before driver's seat.

☐ Movement of controls correct; per installation instructions.

IV. HYDRAULIC INSTALLATION

☐ Correct hydraulic oil level in reservoir per installation instructions.

☐ Inspect for leaks.

Any abnormal noise during hoist operation? ☐ YES ☐ NO

If yes, please describe: _____

With engine operating @ 1,000 RPM, record the following information:

Cycle time for dump mode: _____ Seconds Up _____ Seconds Down
Cycle time for load/unload mode: _____ Seconds to Unload _____ Seconds to Load
Filter pressure: _____ PSI
Main pressure, controls in neutral: _____ PSI

Main relief pressure when ascending:
Jib cylinder (photo red out): _____ PSI

Main relief pressure when ascending:
Jib cylinders (photo red out): _____ PSI

NOTE: Connect pressure gauge to fitting provided on the inlet section of the Hydraulic Control Valve (Ref. Part No. 10P27, fitting on Hydraulic Pump Control Assembly listed in the Parts List section of the Hoist's Parts & Operation Manual)

V. OPERATION

☐ Jib operates freely in both directions.

☐ Jib cannot be extended or retracted when "stop" in dump position or when pivot joint is fixed in unload position. Both safety hooks are fully engaging when jib is extended.

☐ Parts & Operation Manual is in the cab.

☐ Lubricate sliding jib and all grease zerks per installation instructions.

VI. DECALS

☐ All safety decals and product decals installed per provided decal drawings (found attached to the inside of the hoist's Parts & Operation Manual cover or at the back of the Parts List section in the Manual).

Additional Comments: _____

COMPLETE & SAVE TO YOUR COMPUTER. RETAIN A COPY FOR YOUR FILES.
ONCE COMPLETE, FAX (515-313-4426) OR EMAIL (sales@swaploader.net) A COPY BACK TO SWAPLOADER!
1800 NE Broadway Ave., Des Moines, IA 50313 • www.swaploader.com • Toll Free: 888-767-8090

These documents are attached to the inside of this manual's cover and can also be found on swaploader.com.

When the SwapLoader hoist is received from the factory, you should inspect the hoist for damage, which may have occurred in shipment. If damage has occurred, you should contact the shipper immediately. Be sure to note any damage or missing items on bill of Lading.

When you receive your SwapLoader hoist, it is your responsibility to make sure you have received all the parts and pieces that were ordered, within 30 days of the invoice date of the hoist. Lay out all the options, loose parts and accessories on a table and compare the items received vs the Packing List and the Loose Parts Box List(s) shipped with the hoist order.

If you have any problems, shortages, or questions, please contact SwapLoader U.S.A., Ltd. immediately.

GENERAL INSTALLATION PROCEDURE

The installation of the SwapLoader on a truck chassis will generally follow these steps:

1. Install hoist assembly onto truck chassis.
2. Mount the hydraulic control valve to the hoist and install the hydraulic plumbing from the control valve to the hydraulic cylinders. Then install the control levers in the cab and route the control cables to the hydraulic control valve assembly.
3. Install the hydraulic tank, hydraulic filter, and hydraulic plumbing between the hydraulic tank and the control valve assembly.
4. Select and install the P.T.O. on the truck transmission. (Note: This can be done prior to hoist installation on the truck chassis.)
5. Install the hydraulic pump and the plumbing from the pump to the hydraulic tank and control valve assembly.
6. Fill the hydraulic tank with oil, bleed the air from the pump suction line, and start up the unit.

Although SwapLoader attempts to include the mounts and attaching fasteners with each hoist unit, your particular installation may require some additional mounts or modifications. If you have problems with your installation, please contact SwapLoader at 1-888-767-8000, as we may be aware of another customer who has installed a SwapLoader on a similar truck chassis.

HOIST INSTALLATION TO TRUCK CHASSIS

1. Place the SL-520 hoist assembly on the truck chassis. The truck chassis mounting surface should be flat without any steps or protrusions. If necessary shim bars need to be added to ensure a flat surface on which to support hoist. The truck chassis should meet the following minimum specifications (See Figure A):

RBM for each frame channel: 2,500,000 in.-lb.

Total RBM: 5,000,000 in.-lb.

Minimum clear frame rail for mounting: 245" (See Figure A)

Front Axle Cap: 16,000 lb. (Min)

Total Rear Axle Capacity: 38,000 lb. (Min)

CA Dim: 176" to 190" (190" preferred)




Figure A

Note: The above specifications are a minimum requirement. It is the responsibility of the owner/operator to ensure the completed chassis meets or exceeds all federal, state, and local regulations. Also, the hoist should not be used to lift and haul any load that exceeds the load rating of any of the individual components of the completed chassis (tires, axles, suspension, etc.)

The clear frame dimension indicated in the picture above allows for the overall length of the hoist plus 5 inches for cab clearance and rear light bar mounting. Extra frame length may be needed to allow for mounting additional accessories (e.g. Cab Guard, Tarper, Light Kit, Stabilizer, etc.). For example, when mounting a light kit on a truck with a long CA, check that the hoist and the light kit are positioned far enough back to eliminate any interference between the fender and the light kit. You should also consider the final weight distribution with regard to the bridge code when positioning the hoist.

2. There are three types of mount brackets used on the Model SL-520 hoist as indicated in Figure B or Drawing No. 44H44. They are the front chassis mount brackets (44H18), the mid brackets (Pt. No. 88H57), and the rear chassis mount brackets (Pt. No. 44H19).




Figure B

Bolt the mount brackets to the side of the hoist as indicated in Figure B. Adjust locations as necessary to miss chassis suspension, brackets etc. When positioning the brackets allow for mounting the control valve assembly and the hydraulic tank. You should consult the truck chassis supplier for any limitations regarding drilling mount holes in the truck chassis frame rails. Typically, the holes must be at least 2 3/4" from the top of the truck chassis rails (Reference Figure C).




Figure C

Once the locations of the mount brackets have been determined, use the mount brackets as a template for marking the mounting holes in the truck chassis frame rails. Drill the 21/32 diameter holes required to attach the front and rear brackets to the truck chassis with the 5/8-inch diameter bolts, washers, and locking hex nuts provided. Torque to 220 ft.lb. Torque 3/4" carriage bolt nuts for mid brackets to 260 ft. lb.

3. Bolt the mount brackets to the hoist mainframe as indicated on Figures C, D and E. You may need to modify the mount brackets or add shim plates to allow for variances in the width of the truck chassis as well as to allow for top rivets, stepped channels, etc.




Figure D










Figure E



PARTS PER 44H44				
ITEM	PART #	QTY	DESCRIPTION	WT-lb/ea
1	40H34	8	SPRING CAP	0.38
2	44H18	4	CHASSIS MNT BRKT, SHORT	5.19
3	44H19	4	CHASSIS MNT BRKT, LONG	7.93
4	44H21	1	PARTS & OP MANUAL	0.01
5	44H22	1	DECAL ASSEMBLY	0.01
6	88H57	6	FRONT BRACKET	5.54
7	00755	7	3/8" LOCK WASHER	0.00
8	00785	46	5/8" H.T. WASHER	0.05
9	00786	12	3/4" H.T. WASHER	0.06
10	00P14	7	3/8-16 HEX NUT	0.02
11	00P44	4	3/8-16 x 1 1/2" BOLT	0.06
12	00P55	46	5/8-11 LOCKING NUT	0.08
13	00P69	38	5/8-11 x 2" HHCS (GR. 8)	0.23
14	00P72	12	3/4-10 LOCKING HEX NUT	0.13
15	00P92	8	5/8-11 x 4" HHCS	0.41
16	00P99	3	3/8-16 x 4" HHCS	0.14
17	01P54	12	3/4-10 x 2" CARRIAGE BOLT	0.36
18	10P63	2	5/16-18 x 1 3/4" HEX BOLT	0.04
19	10P64	2	COVER PLATE	0.10
20	10P65	2	HOSE CLAMP	0.07
21	90P30	8	SPRING CYLINDER	0.01
				116.56





An EPFO Company


SWAPLOADER

U.S.A. LTD

HOIST INSTALLATION ASS'Y
SL-520
44H44


CONTROLS INSTALLATION - MANUAL

1. Attach the valve mount bracket (Pt. No. 40H43) to the mainframe as indicated on Dwg. No. 90H49 with the fasteners provided (See Drawing 44H44).
2. Mount the hydraulic control valve assembly (Pt. No. 20P59) to the valve mount bracket as shown on Drawing No. 90H49 with the fasteners provided.
3. Install the hydraulic adapters, connect the hydraulic tubing (Pt. No. 13P30 & 13P31), and connect the hydraulic hose assemblies (Pt. Nos. 11P56 and 11P57) to the control valve assembly as indicated on Drawing No. 91H26. The clamp assemblies that are provided in the Loose Parts Box should support the tubing (See Drawing 44H44).
4. Determine the best location in the cab for the control levers (Pt. No. 20P08). The location should be such that the controls can be easily reached while operating the truck. A control lever console (Pt. No. 20P09) is provided to facilitate the mounting of the control levers.
5. Assemble and install the control lever console (See diagram below). Typically the console is fastened to the floor of the cab and the control cables are routed through additional holes drilled in the floor. Your particular installation may require that additional brackets be fabricated or other modifications made.



SERVICE PARTS LIST FOR 20P59	
P/N	DESCRIPTION
21P18	HYDRAULIC RELIEF VALVE CARTRIDGE (3,500 PSI)

PARTS LIST					
ITEM	QTY	P/N	DESCRIPTION	WT-lb/ea	REMARKS
1	ONE	40H43	VALVE MOUNT BRACKET WDMT	13.13	
2	2	20P08	REMOTE VALVE CONTROL HANDLE	2.80	
3	ONE	20P09	CONTROL HANDLE MOUNT CONSOLE	4.05	
4	2	20P40	CONTROL CABLE 96" LG	2.00	
5	2	20P65	BONNET CONNECTION KIT	0.50	
6	ONE	20P59	HYD VALVE ASS'Y	46.00	
				73.78	TOTAL



NOTE:
A 2 SECTION CONTROL VALVE ASS'Y IS SHOWN. A 3 SECTION CONTROL VALVE ASS'Y IS REQUIRED WHEN A STABILIZER IS UTILIZED




MANUAL CONTROL ASS'Y - 2 SECTION

SL-518/520/650

90H49 ~ REV A

PARTS PER 91H26

ITEM	QTY.	PART #	DESCRIPTION	WT-lb/ea.
1	2	10P36	ADP, HYD MJIC/ORB 90°	0.40
2	1	10P37	ADP, HYD MJIC/MP 90°	0.30
3	1	10P38	ADP, HYD FMJIC CAP	0.10
4	2	10P78	T-BOLT CLAMP, Ø1 3/4"	0.15
5	1	11P56	HOSE ASS'Y 3/4 H.P. x 28	2.36
6	1	11P57	HOSE ASS'Y 3/4 H.P. x 33	2.72
7	2	11P62	ADP, HYD MJIC/ORB LL 90°	0.40
8	2	11P65	ADP, HYD MJIC/FMJIC SVL 90°	0.40
9	1	11P78	ADP, HYD MP/MP	0.70
10	1	12P25	ADP, HYD HOSE INS/MP	0.60
11	1	12P27	ADP, HYD HOSE INS/ORB 90°	0.70
12	1	12P33	HOSE 1 1/4 LP x 36	2.37
13	1	13P30	HYD TUBING - REAR LOWER	7.91
14	1	13P31	HYD TUBING - REAR UPPER	8.29
15	1	20P61	HYD FILTER	4.50
16	1	20P64	FILTER INDICATOR GAUGE	-
17	1	20P86	HYD TANK - 30 GAL	73.00
TOTAL				106.25



SHOP NOTES:

1. HYD TANK ASS'Y CONSISTS OF: TANK
WELDMENT, TANK MOUNTED STRAINER,
SIGHT GAUGE, FILLER/BREATHING CAP,
MAGNETIC DRAIN PLUG, AND PORT PLUGS.



HYD SUB-ASS'Y CHASSIS TANK CIRCUIT


SL-520

91H26

6. Attach the control cables to the control levers and route the cable through the holes in the cab. Install the control levers in the console. Levers should be installed such that when the levers are pushed forward the control cable is extended. See Drawing No. 90H49 (Manual Control Assembly) for control lever orientation.
7. Route the cables to the control valve location and attach them to the control valve with the bonnet connection kits provided (Pt. No. 20P65). See the following instruction sheet for installation procedures. The control cables supplied are 96 inches long. Your particular mounting may require different length control cables, which can be purchased locally or through SwapLoader. Take proper care when routing the control cables, as a good cable path is essential for a proper operating system. Keep bends in the cable path to a minimum and be as generous as possible. Under no circumstances should any bend be tighter than an 8" radius. Protect the cable from heat above 225 degrees F. and avoid hot areas such as exhaust pipes, etc... Protect the cable from physical damages such as pinching or crushing, and do not use cable supports, which may crush or deform the cable. Allow room for flexing where the cable is attached to moving parts of the equipment, so that the cable is neither kinked nor stretched.


**INSTALLATION PROCEDURE FOR A HYDRAULIC CONTROL
CABLE TO HYDRAULIC VALVE WITH BONNET CONNECTION KIT**

1. Turn .750-16 UNF Jam Nut entire length of Threaded Hub back over the Cable. Place Flange onto Sleeve (large end first) and Flange onto Sleeve and turn Flange Adaptor / Flange / Sleeve Assembly entire length of Threaded Hub back over the Cable.
2. Turn .250-28 UNF Jam Nut onto Cable Threaded Rod until it bottoms.
3. Place Clevis of Threaded Rod and bottom against Jam Nut. Turn other .250-28 UNF Jam Nut onto Threaded Rod until it bottoms against Clevis. Align Clevis so it will mate with Spool Terminal Eye and secure Jam Nut against Clevis.
4. Slide the Clevis onto Terminal Eye on spool and align the holes. Insert Clevis Pin through yoke and Terminal Eye holes and secure Clevis Pin with Retaining Ring.
5. Now, with the Cable attached to the valve and control head, turn the Flange Adapter / Flange / Sleeve Assembly back onto the Threaded Hub until it is flush with the valve face. When turning on the Flange Adapter / Flange / Sleeve Assembly, make sure that the control head remains in the neutral position.
6. Tighten the .750-16 UNF Jam Nut against the Sleeve and lock in position.
7. Bring Flange into position on bolt assembly to valve housing.





CONTROLS INSTALLATION - AIR SHIFT (OPTION)

1. Attach the valve mount bracket (Pt. No. 40H43) to the mainframe as indicated on Drawing No. 90H47 with the fasteners provided (See Drawing 44H44).
2. Mount the hydraulic control valve assembly (Pt. No. 90H41) to the valve mount bracket as shown on Drawing No. 90H47 with the fasteners provided.
3. Install the hydraulic adapters and connect the hydraulic hose assemblies (Pt. Nos. 11P56 and 11P57) and the hydraulic tubing (Pt. No. 13P30 & 13P31) to the control valve assembly as indicated on Drawing No. 91H26. The clamp assemblies that are provided in the Loose Parts Box should support the tubing (See Drawing 44H44).
4. Determine the best location in the cab for the control handle assembly (Pt. No. 20P72). The location should be such that the controls can be easily reached while operating the truck. A control handle console (Pt. No. 51H27) is provided to facilitate the mounting of the control handles (See diagram below).
5. Install the air fittings and hose as shown on Drawing No. 90H44 (Air Circuit, Control Valve). An air pressure protection valve (Pt. No. 20P74) is provided so you can tap into the truck's air supply without jeopardizing the integrity of the air system. The air hose is provided in bulk length, which you can cut to length as required for running the air lines. Take care in routing the air lines and avoid hot areas such as exhaust pipes, etc.



SERVICE PARTS LIST FOR 20P59	
P/N	DESCRIPTION
21P18	HYDRAULIC RELIEF VALVE CARTRIDGE (3,500 PSI)

PARTS LIST					
ITEM	QTY	P/N	DESCRIPTION	WT-lb/ea	REMARKS
1	ONE	40H43	VALVE MOUNT BRACKET	13.13	
2	ONE	20P72	CONTROL HANDLE ASS'Y	1.60	
3	ONE	20P59	HYD CONTROL VALVE ASS'Y	46.00	
4	ONE	12P94	AIR LINE KIT	1.40	
5	ONE	51H27	AIR CONTROL CONSOLE ASS'Y	6.23	
6	2	20P71	HYD VALVE SECTION AIR SHIFT KIT	1.50	
7	ONE	20P74	AIR PRESSURE PROTECTION VALVE	0.59	WM778A
				71.95	TOTAL




- NOTE:
- 20P71 AIR SHIFT KIT TO BE INSTALLED ON HYD CONTROL VALVE BY HOIST INSTALLER. REFERENCE INSTALLATION INSTRUCTIONS INCLUDED WITH THE AIR SHIFT KIT.
 - SEE DRAWING 90H44 FOR AIR SHIFT KIT PLUMBING DIAGRAM.



AIR CONTROL ASS'Y - 2 SECTION

SL-505/518/520/650

90H47 ~ REV C



- NOTE:
1. FITTINGS AND TUBING SHOWN ARE PART OF THE 12P94 AIR LINE KIT.
 2. THE 12P94 AIR LINE KIT CONTAINS FITTINGS FOR MULTIPLE PLUMBING CONFIGURATIONS AND NOT ALL FITTINGS MAY BE UTILIZED.



AIR CIRCUIT, CONTROL VALVE - 2 SECTION

SL-505/518/520/650

90H44 ~ REV B

HYDRAULIC TANK INSTALLATION

1. Select a location to mount the hydraulic tank. Reference Figure F or Drawing No. 90H49 for the suggested location of the hydraulic tank to the rear of the control valve assembly on the left-hand side of the truck. The hydraulic hoses have been sized for the tank to be mounted in this general area. The tank can be located on the right-hand side or behind the cab, if necessary, which means longer hoses may be required.
2. Drill four (4) holes for 1/2-inch diameter bolts (provided) in the mount angle of the hydraulic tank (two per angle) and the frame rails of the truck chassis. Mount the hydraulic tank and install the hydraulic filter. Install the hydraulic return hose and the hose barb fitting between the filter and the control valve assembly as shown on Drawing No. 91H26. The hose length can be shortened if necessary. Secure the hose to the barb fittings with the hose clamps provided.




Figure F

P.T.O. SELECTION

The next step is to select and install a direct drive type P.T.O. to the transmission. Please contact your local truck equipment representative for the correct unit sized on the following criteria:

P.T.O. Torque Rating:	230 ft.-lbs. (See Note 1)
Power at 1500 RPM:	66 H.P. (See Note 1)
Mount Flange (Direct Mount)	SAE B 4 Bolt
Hydraulic Pump Spline Shaft Specifications:	7/8-13T 16/32 D.P.
Hydraulic Pump Rotation:	L.H. and R.H. Available (See Note 2).

NOTE 1: P.T.O. torque and power requirements are based on the unit operating at main relief pressure. Normal operating pressure will be less.

NOTE 2: P.T.O. output rotation will need to be R.H. (clockwise) as viewed looking at output flange of P.T.O. for a L.H. Pump.

NOTE 3: Do not operate pump at speeds over 1500 R.P.M.

NOTE 4: Always disengage the P.T.O. after each operating cycle.

HOW TO IDENTIFY WHAT PUMP IS NEEDED

The SwapLoader factory supplied pump is a bushing style gear pump, because of the pressure requirements of the SwapLoader hooklift hoist. By design the bushing style pumps are single rotation (rotation specific).


All SwapLoader hooklift hoists can be ordered with a CCW, left hand rotation pump or CW, right hand rotation pump. **NOTE: Consult the PTO supplier whenever uncertain about the correct pump rotation for a particular application.**

The table below lists the SwapLoader part number for both left and right hand rotation pumps for the SL-520 hoist model:

MODEL	L.H. Rotation Pump	R.H. Rotation Pump
SL-520	22P44	22P45

HOW TO IDENTIFY PUMP ROTATION

To better understand the effects of pump rotation we must consider the path that oil takes through the pump. Oil enters the pump through the inlet (suction) port, travels around the outside of the gears, and is forced out through the outlet (exhaust) port. Oil enters and exits the pump in the direction of its rotation.



Determine pump rotation by positioning the pump belly side down (see illustration above). Looking at the rear of the pump if the suction (largest) port is to the left side, then the pump is a CCW or left hand rotation. If the suction (largest) port is on the right side, then the pump is CW or right hand rotation.

PUMP INSTALLATION


1. Install the hydraulic pump to the P.T.O. (Bolts are not provided).
2. Install the hydraulic fittings into ports on the hydraulic pump as shown on Drawing No. 91H19.
3. Connect the suction hose assembly to the hydraulic tank (1 1/2" I.D. hose) and route to the hydraulic pump in as short and straight line as possible. Be sure to route the hose clear of exhaust components and of the drive shaft. Extra hose is provided so the hose can be shortened to an appropriate length. Install the hose on the hose barb fittings at the tank and at the pump and secure with the hose clamps provided.

NOTE: Prior to startup, this hose must be filled with oil.


4. The pressure hose the hydraulic pump to the control valve assembly is not supplied with the hoist as it must be made to the proper length. This hose must be purchased from a local hydraulic hose assembly supplier per the following specifications:

Hose I.D.:	1 inch
Working Pressure:	3500 PSI
Hose Fitting Threads:	SAE 37° (JIC) 1 5/16-12

5. Install the pressure hose as indicated. Tie up the pressure and suction hoses as necessary. Again, be sure the hoses are routed to avoid exhaust components and to stay clear of the drive shaft.



PARTS PER 91H19				
ITEM	QTY	PART#	DESCRIPTION	REMARKS
1	1	10P31	ADP, HYD M/JC / ORB 45°	6802-16
2	1	11P71	HOSE 1 1/2 LP x 120	
3	1	11P74	ADP, HYD M/JC / ORB	6400-16-12
4	2	11P77	T-BOLT CLAMP, Ø2"	TBC-200
5	2	11P95	ADP, HYD HOSE INS / MP	STC-20
6	1	12P48	ADP, HYD MP / FP	2 x 1 1/2



SWAPLOADER™
USA LTD.


HYD SUB-ASS'Y - PUMP CIRCUIT

SL-518/520

91H19

START UP PROCEDURE

1. Fill the hydraulic tank with hydraulic oil (see oil specification in Maintenance Section.)
2. Prime the pump by loosening the clamp on the suction hose at the pump. Pull the hose back off the fitting till the air is bled from the line. Push the hose back on the fitting and retighten the clamp.
3. Engage the P.T.O. and run the pump at idle (700 to 900 RPM). Operate the cylinders at full stroke five to ten times to bleed the air from the lines and cylinders. The cylinders were filled with oil during testing at the factory, but some seepage may have occurred during shipping and installation. Refill the hydraulic tank, if needed, during this sequence and do not let the pump run without oil.
4. Check for leaks and tighten fittings as necessary.
5. Verify the movement of the control levers corresponds to the movement of the cylinders per the figure below.



6. Install all safety decals and product decals per Drawing No. 40H98 after final installation and painting have been completed. The factory prior to shipment of a hoist, will install some decals that have a premask layer. The premask will need to be removed after painting the hoist. It is very important when removing the premask not to pull the premask out and away from the decal at a 90° angle, but instead pull the premask straight down at a 180° angle to the decal surface. Should problems occur with the premask pulling the decal loose, wet the tack side of the premask with water via a spray bottle to weaken the adhesive bond, while pulling straight down on the premask.

7. Fill out pre-delivery checklist and warranty card and email to SwapLoader U.S.A., Ltd. These pages can be found in Section 1.

NOTE: Failure to fill out and return warranty card within 15 days of installation may possibly void the warranty.



CAUTION: The SwapLoader hoist must be used with bodies or containers that properly fit the front hook and the rear hold-downs (See drawings S935 & S936). If possible, pick up one of the containers that will actually be used with the SwapLoader hoist and verify the following:


- Outside dimensions of the long sills match the guiding rollers on the hoist.
 - The front hook dimensions are correct for the hoist.
 - The rear hold-downs of the container latch into the hold-downs on the hoist.
 - Check for any interference between the container and any part of the hoist (i.e.: Hydraulic tank, hydraulic tubing or hose, hydraulic valve, etc.)
-



An EFCO Company

SWAPLOADER®
"Hooked on Quality"
U.S.A. LTD.

300 SERIES SUB-FRAME CRITICAL DIMENSIONS



300 SERIES SUB-FRAME DIMENSIONS


HOIST COMPATABILITY	A	B
SL-180/185/240/330/400/412	111 3/4" [2839 mm]	36" [915 mm]
SL-205/220/222/406/518	123 3/4" [3143 mm]	48" [1220 mm]
SL-520	154 1/2" [3925 mm]	48" [1220 mm]

NOTES

1.) A STRUCTURAL JIB CONTACT POINT LOCATED AS LOW AS ALLOWABLE ON THE FRONT OF THE BODY IS REQUIRED.

2.) WELD HOOK GUARD TO BODY OR ADD STRUCTURAL SUPPORT AS NEEDED FOR THE APPLICATION.

3.) THIS DRAWING PROVIDES THE CRITICAL SUB-FRAME DIMENSIONS FOR COMPATABILITY WITH THE SWAPLOADER HOOK LIFT HOIST. IT IS THE SUB-FRAME SUPPLIERS RESPONSIBILITY TO PROVIDE A SUB-FRAME OF SUFFICIENT CAPACITY WHICH PROPERLY SUPPORTS THE BODY/CONTAINER WHEN USED WITH THE HOOK LIFT HOIST.

		
TITLE 300 SERIES SUB-FRAMES		
DRAWING NO. S-935	MODEL NO.	REV B





An EFCO Company

SWAPLOADER®

U.S.A. LTD.

400 SERIES SUB-FRAME CRITICAL DIMENSIONS



400 SERIES SUB-FRAME DIMENSIONS

HOIST COMPATIBILITY	A	B
SL-412	111 3/4" [2839 mm]	36" [915 mm]
SL-240/330/400	123 3/4" [3143 mm]	36" [915 mm]
SL-220/222/405/406/518/545	132 1/8" [3356 mm]	48" [1220 mm]
SL-375/505/520/650/655	154 1/2" [3925 mm]	48" [1220 mm]

NOTES

1.) A STRUCTURAL JIB CONTACT POINT LOCATED AS LOW AS ALLOWABLE ON THE FRONT OF THE BODY IS REQUIRED.

2.) WELD HOOK GUARD TO BODY OR ADD STRUCTURAL SUPPORT AS NEEDED FOR THE APPLICATION.

3.) THIS DRAWING PROVIDES THE CRITICAL SUB-FRAME DIMENSIONS FOR COMPATABILITY WITH THE SWAPLOADER HOOK LIFT HOIST. IT IS THE SUB-FRAME SUPPLIERS RESPONSIBILITY TO PROVIDE A SUB-FRAME OF SUFFICIENT CAPACITY WHICH PROPERLY SUPPORTS THE BODY/CONTAINER WHEN USED WITH THE HOOK LIFT HOIST.



SWAPLOADER

U.S.A. LT

TITLE	
-------	--

400 SERIES SUB-FRAMES

DRAWING NO.

S-936


MODEL NO.

REV

E

STABILIZER INSTALLATION (OPTION)

1. The hoist installation for a unit with the stabilizer option is much the same as that for the standard unit except that a three section hydraulic control valve is used. (See Drawing No. 90H49 for Manual Control or Drawing No. 90H47 for Air Controls for the correct installation and plumbing diagrams for a hoist with three control circuits in the Option section of the Parts List pages of the manual).
2. The following diagram gives the approximate position of the stabilizer roller from the top of the truck chassis frame rail with the mounts as provided by SwapLoader. When extended down, the roller should touch the ground only when the vehicle is loading a heavy container. Therefore, with the truck empty, leave 2 to 3 inches of clearance between the ground and the roller.




Also, you will need to check that when the roller is up in the transport position it does not interfere with any part of the rear axle, rear suspension, or brake components. If some interference will occur, you may slant the stabilizer mounting back from the vertical position until you leave sufficient clearance. This can be achieved by cutting the truck chassis frame rails off at an angle before installing the stabilizer mounts. Do not slant the mounting more than eight degrees (about a 14:2 pitch).

3. Once the required position of the stabilizer has been determined, install as shown on drawing 42H62 in the Options section of the hoist manual. [*Field weld size requirements are also indicated on drawing 42H62 in the Options section of the hoist manual.*]


Note: Prior to any welding, consult the truck manufacturer for any special precautions that may need to be taken. Typically the batteries must be disconnected and the ground lead from the welder should be connected as close as possible to the part being welded to avoid the possibility of arching across bearings, gears, etc.

Note: The hoist mainframe is made from high strength low alloy steel. Use an appropriate welding process.

4. Install the hydraulic adapters and hoses from the three section hydraulic control valve to the hydraulic cylinder (Pt. No. 21P84) shown on drawings 42H62 & 90H83 in the Option section of the manual. Tie up all loose hoses as required. Be sure the hoses are routed to avoid exhaust components and all moving components of the rear axles.
5. After the start procedure has been completed on the hoist, verify that the movement of each control lever corresponds to the movement of the cylinders per the figure below.




Operate the stabilizer through 5 to 8 cycles to remove the air from the hydraulic cylinders and lines.



An EFCO Company

SWAPLOADER[®]
U.S.A. LTD.



REAR BUMPER ASSEMBLY

(52H11)

REAR BUMPER ASSEMBLY

(52H11)

INSTALLATION INSTRUCTIONS

1. Review all directions and diagrams provided before starting bumper installation.
2. Trim truck frame to indicated dimensions (See Figure 1). These dimensions will facilitate the mounting of the rear light assembly if it is also being mounted.
3. Measure the distance from the top of the truck frame to the ground (NOTE: This should be performed on a level surface). Based on this measurement and the dimensions in Figure 1, the vertical channel [Part No. 63H94] may need to be modified in length to meet the Office of Motor Carrier Safety (OMCS) regulations. Regulation 393.86 requires that no bumper be located more than 30" off the ground when the truck is empty, and the end of the bumper should not be located more than 24" from the extreme rear of the vehicle, including truck bodies (See Figure 2). Once the length has been determined for the vertical channels, weld them to the bottom of the truck frame (See additional notes on next page).
4. Center the bumper weldment [Part No. 52H12] on the vertical channels [Part No. 63H94]. Position rear of bumper from rear of the hoist as indicated by the bumper location chart. This is crucial in order to ensure that the container longsills do not contact the bumper during the dump cycle (See Figure 1 & 2).
5. Weld the bumper weldment to the vertical channels (See Figure 1 & 3).




Figure 1




Figure 2

REAR BUMPER ASSEMBLY

(52H11)

BUMPER LOCATION CHART									
DIM. A	DIMENSION B (Max)								
	SL-105	SL-145	SL-180 SL-185	SL-220 SL-222 SL-240	SL-2418	SL-330 SL-400	SL-412	SL-406 SL-518 SL-520	SL-650
24 5/8"	13 1/2"	15 3/4"	15 1/4"	17"	14 1/4"	14"	13 1/2"	16 1/2"	18"
22 5/8"	12 1/4"	14 1/2"	14"	15 3/4"	13"	12 3/4"	12"	15"	
20 5/8"	11"	13"	12 3/4"	14 1/4"	11 3/4"				
18 5/8"	9 3/4"	11 3/4"	11 1/2"						

Additional Notes:

1. Prior to any welding, consult the truck manufacture for any special precautions that may need to be taken. Typically the batteries must be disconnected and the ground lead from the welder should be as close to the part being welded to avoid the possibility of arcing across bearings, gears, etc.
2. All welds should be done utilizing a low hydrogen welding process.





Figure 3


MATERIAL LIST				
ITEM	QTY	P/N	DESCRIPTION	WT lb PER EA.
1	1	52H12	REAR BUMPER WELDMENT	95.66
2	2	63H94	VERTICAL CHANNEL	9.58
TOTAL				114.82



An EFCO Company

SWAPLOADER®

U.S.A. LTD.



REAR BUMPER ASS'Y w/ EXTENSIONS

(52H11 with 52H13 Extensions)

REAR BUMPER ASS'Y w/ EXTENSIONS

(52H11 with 52H13 Extensions)

INSTALLATION INSTRUCTIONS

1. Review all directions and diagrams provided before starting bumper installation.
2. Trim truck frame to indicated dimensions (See Figure 1). These dimensions will facilitate the mounting of the rear light assembly if it is also being mounted.

3. Measure the distance from the bottom of the truck frame to the ground (NOTE: This should be performed on a level surface). Based on this measurement and the dimensions in Figure 1, the vertical channel [Part No. 63H94] may need to be modified in length to meet the Office of Motor Carrier Safety (OMCS) regulations. Regulation 393.86 requires that no bumper be located more than 30" off the ground when the truck is empty, and the end of the bumper should not be located more than 24" from the extreme rear of the vehicle, including truck bodies (See Figure 2). Once the length has been determined for the vertical channels, weld them to the truck frame (See additional notes on the next page).




Figure 1

4. Center the bumper weldment [Part No. 52H12] with factory installed extensions Part No. 52H13] on the vertical channels [Part No. 63H94]. Position rear of bumper from rear of the hoist as indicated by the bumper location chart. This is crucial in order to ensure that the container longsills do not contact the bumper during the dump cycle (See Figures 1 & 2).
5. Weld the bumper weldment to the vertical channels (See Figure 1 & 3).




Figure 2

REAR BUMPER ASS'Y w/ EXTENSIONS

(52H11 with 52H13 Extensions)

BUMPER LOCATION CHART									
DIM. A	DIMENSION B (Max)								
	SL-105	SL-145	SL-180 SL-185	SL-220 SL-222 SL-240	SL-2418	SL-330 SL-400	SL-412	SL-406 SL-518 SL-520	SL-650
24 5/8"	1 3/4"	22 1/2"	21 3/4"	25 1/4"	21 3/4"	* 21 1/2"	* 21 1/4"	* 24 1/4"	27"
22 5/8"	18 1/2"	21"	20 1/2"	23 3/4"	20 1/2"	* 20"	* 19 3/4"	* 22 3/4"	
20 5/8"	17 1/4"	19 1/2"	1 1/4"	22 1/4"	19 1/4"				
18 5/8"	16"	18 1/4"	18"						

* Dimensions assume 6" tall longsills. For 8" tall longsills add 2 1/4" to the dimension shown.

Additional Notes:

1. Prior to any welding, consult the truck manufacture for any special precautions that may need to be taken. Typically the batteries must be disconnected and the ground lead from the welder should be as close to the part being welded to avoid the possibility of arcing across bearings, gears, etc.
2. All welds should be done utilizing a low hydrogen welding process.





Figure 3


MATERIAL LIST				
ITEM	QTY	P/N	DESCRIPTION	WT lb PER EA.
1	1	52H12	REAR BUMPER WELDMENT	95.66
2	1	52H13	REAR BUMPER EXTENTIONS	58.42
3	2	63H94	VERTICAL CHANNEL	9.58
TOTAL				173.24



An EFCO Company

SWAPLOADER®

U.S.A. LTD.



FOLDING BUMPER

(51H44)

FOLDING BUMPER

(51H44)

INSTALLATION INSTRUCTIONS

1. Review all directions and diagrams provided before starting bumper installation. Typically, a folding bumper is needed when the rear of the container extends beyond the back of the truck such that the distance between the truck bumper and container rear exceeds 24" (See Figure 1).

Office of Motor Carrier Safety (OMCS) Regulation 393.86 requires that no bumper be located more than 30" off the ground when the truck is empty, and the end of the bumper should not be located more than 24" from the extreme rear of the vehicle, including truck bodies (See Figure 1). The folding bumper will need to be used in conjunction with the Roller Assembly [Part No. 10H90] and Roller Mount Brackets Assembly [Part No. 10H90] for the container to function properly.




Figure 1

2. Locate the best position for the support bars between the cross members. Fabricate four support bars out of 4" x 1" bar cut to the length needed to fit between the cross members (See Figure 3).

Figure 3 shows a width dimension of 56 1/2". This width can be adjusted if interference occurs with other items on the container, but cannot exceed the width of the bumper tube. Weld the four bars between the cross members.




Figure 2


3. Weld the front [Part No. 62H87] and rear [Part No. 62H88] brackets to the support bars. Be sure to maintain the dimensions as indicated so that the bumper folds properly (See Figure 2 & 3).

FOLDING BUMPER

(51H44)

INSTALLATION INSTRUCTIONS (cont'd)

4. Weld the Pivot Arms [Part No. 62H84 to the Bumper Tube Weldment [Part No. 51H46]. Be sure to maintain the width dimension that was used to locate the support bars in Step 2.
5. Assemble the Bumper Assembly to the Front and Rear Brackets (See Figure 3). Refer to the Typical Bolted Connection (See Figure 3) for all connections.
6. Raise the bumper into the folded position several times to ensure the mechanism works smoothly and freely.




Additional Notes:

Figure 3

1. Prior to any welding, consult the truck manufacture for any special precautions that may need to be taken. Typically the batteries must be disconnected and the ground lead from the welder should be as close to the part being welded to avoid the possibility of arcing across bearings, gears, etc.
2. During installation of the bumper, check to make sure that the position of the bumper does not interfere with the loading and unloading of truck bodies.


MATERIAL LIST				
ITEM	QTY	P/N	DESCRIPTION	WT lb PER EA.
1	2	51H45	SLIP BRACKET WDMT	9.71
2	1	51H46	BUMPER TUBE WDMT	47.83
3	2	62H84	PIVOT ARM	24.79
4	2	62H85	SLIDE ARM	10.67
5	8	62H86	BUSHING	0.39
6	4	62H87	FRONT BRACKET	4.45
7	4	62H88	REAR BRACKET	3.16
8	8	01P15	3/4-10 x 3 HHCS	0.56
9	8	00P72	3/4-10 LOCKING HEX NUT	0.20
10	16	00774	Ø3/4 FLAT WASHER	0.05
TOTAL				177.53



An EFCO Company

SWAPLOADER[®]

U.S.A. LTD.



BUMPER ASSEMBLY, DROP DOWN (51H11)

BUMPER ASSEMBLY, DROP DOWN

(51H11)

INSTALLATION INSTRUCTIONS

1. Review all directions and diagrams provided before starting bumper installation. Typically, a drop down bumper is needed when the rear of the container extends beyond the back of the truck such that the distance between the truck bumper and container rear exceeds 24" (See Figure 1). Office of Motor Carrier Safety (OMCS) Regulation 393.86 requires that no bumper be located more than 30" off the ground when the truck is empty, and the end of the bumper should not be located more than 24" from the extreme rear of the vehicle, including truck bodies (See Figure 1).
2. Position drop down bumper on the longsills of the sub-frame (See Figure 2 & 3). The mount brackets [Part No. 51H17] need to be positioned correctly to allow for sufficient room for bumper cradles [part no. 51H19] (See Figure 2). Weld mount brackets onto the longsills of the sub-frame.
3. Position bumper cradles [Part No. 51H19] on the longsills of the sub-frame. Check bumper cradles for squareness with respect to each other. The bumper tube [Part No. 51H16] should come to rest within the bumper cradles when the container rests on the ground (See Figure 2 & 3). Weld bumper cradles into place on longsills.




Figure 1




Figure 2

BUMPER ASSEMBLY, DROP DOWN

(51H11)

Additional Notes:

1. Prior to any welding, consult the truck manufacturer for any special precautions that may need to be taken. Typically the batteries must be disconnected and the ground lead from the welder should be connected as close as possible to the part being welded to avoid the possibility of arcing across bearings, gears, etc.
2. During installation of the bumper, check to make sure that the position of the bumper does not interfere with the loading and unloading of truck bodies.





Figure 3


MATERIAL LIST				
ITEM	QTY	P/N	DESCRIPTION	WT lb PER EA.
1	1	51H12	LONG PIVOT ARM R.H	16.08
2	1	51H13	LONG PIVOT ARM L.H.	16.08
3	1	51H14	SHORT PIVOT ARM R.H.	8.89
4	1	51H15	SHORT PIVOT ARM L.H.	8.89
5	1	51H16	BUMPER TUBE	113.05
6	2	51H17	MOUNT BRACKET	19.94
7	4	51H18	BUMPER PIN	1.12
8	2	51H19	BUMPER CRADLE	1.64
9	2	51H20	BUMPER ROLLER	27.07
10	6	01P06	3/4-10 SLOTTED HEX NUT	.22
11	6	00786	Ø3/4 FLAT WASHER HT	.10
12	6	00P98	Ø5/32 x 1 1/2 COTTER PIN	.01
13	4	00P03	3/8-16 x 3/4 HHCS	.11
14	4	00755	Ø3/8 LOCK WASHER	.05
15	10	90P20	1/4-8 GREASE ZERK	.01
16	2	90P03	1-1/8 O.D. x 10 SPRING	.60
TOTAL				288.69



An EFCO Company

SWAPLOADER®

U.S.A. LTD.



CAB GUARD ASSEMBLY (50H99)

CAB GUARD ASSEMBLY

(50H99)

INSTALLATION INSTRUCTIONS

1. Review all directions and diagrams provided before starting cab guard installation.
2. Position cab guard weldment [Part No 50H95] on frame with sufficient clearance between cab and cab guard.
3. Determine location for mounting holes. Mounting holes should not be located within 2 3/8" of the truck frame edge (see Figure 1). Drill Ø21/32" mount holes through cab guard channels.
4. Mark mounting holes through the cab guard weldment onto truck frame. Remove cab guard weldment and drill Ø21/32" holes in truck frame.
5. Attach cab guard weldment to truck frame using fasteners provided (see Figure 2).




Figure 1






Figure 2

MATERIAL LIST				
ITEM	QTY	P/N	DESC.	WT lb PER EA.
1	1	50H95	CAB GUARD WDMT	295.36
2	4	00P69	5/8-11 x 2 HHCS	0.33
3	4	00P55	5/8-11 LOCKING HEX NUT	0.18
4	4	00785	Ø5/8" WASHER HT	0.08
TOTAL				292.72



An EFCO Company

SWAPLOADER[®]
U.S.A. LTD.



FENDER ASSEMBLY, TANDEM AXLE

Steel (11H14)

FENDER ASSEMBLY, TANDEM AXLE

Steel (11H14)

INSTALLATION INSTRUCTIONS

1. Review all directions and diagrams provided before starting fender installation.
2. Center fender above tire using block to maintain the proper height. Fender should be approximately 6" above tire to allow for suspension movement (see Figure 1). A maximum width of 48" from center of the truck to the outside edge of the fender should be maintained (see Figure 2).

3. Place fender bracket weldments [Part No. 10H74] on fender. Position the brackets to avoid any mounting obstacles on hoist and/or truck chassis.
4. Mark mounting holes through the fender bracket weldment onto the fender. Remove the bracket and drill $\varnothing 7/16"$ holes in fender (see Figure 3).




Figure 1

5. Attach fender bracket weldments to fender using fasteners provided.
6. Weld mounting plates [Part No. 21H37] to fender tubes [Part No. 21H61].
7. Position fender tubes with mount plates on hoist main frame; align with fender bracket weldments. (**NOTE: Fender tube length may need to be modified to fit specific application.**)
8. Weld fender tubes to hoist main frame. If attaching the fender tubes to the truck chassis, an additional mount plate may need to be fabricated so the assembly can be bolted to the truck chassis.
9. Attach fender bracket weldment [Part No. 10H74] to mounting plate [Part No. 21H37] using fasteners provided (see Figure 3).




Figure 2

FENDER ASSEMBLY, TANDEM AXLE

Steel (11H14)





Figure 3

MATERIAL LIST				
ITEM	QTY	P/N	DESCRIPTION	WT lb PER EA.
1	6	10H74	FENDER BRACKET WDMT	8.05
2	6	21H37	MOUNTING PLATE	1.09
3	6	21H42	RUBBER SPACER	0.85
4	6	21H61	FENDER TUBE	1.26
5	48	00P34	3/8-16 UNC LOCKING NUT	0.02
6	24	00P44	3/8-16 UNC x 1 1/2 HHCS	0.07
7	24	00P78	Ø3/8" NYLON WASHER	-
8	8	00P99	3/8-16 UNC x 4 HHCS	0.11
9	16	01P21	3/8-16 UNC x 2 1/2 HHCS	0.09
10	2	90P36	FENDER, STEEL TANDEM	77.00
11	72	00771	Ø3/8" FLAT WASHER	0.05
TOTAL				228.86

Additional Notes:


1. Prior to any welding, consult the truck manufacturer for any special precautions that may need to be taken. Typically the batteries must be disconnected and the ground lead from the welder should be as close to the part being welded to avoid the possibility of arcing across bearings, gears, etc.



An EFCO Company

SWAPLOADER[®]

U.S.A. LTD.



REAR LIGHT BAR ASSEMBLY (LED-LB)

REAR LIGHT BAR ASSEMBLY

(LED-LB)

INSTALLATION INSTRUCTIONS

1. Review all directions and diagrams provided before starting rear light bar installation.
2. Trim truck frame to indicated dimensions (See Figure 1). This step may have already been performed if a bumper was previously installed.




Figure 1

3. Position center plate [Part No. 63H08] on the rear of the main frame. Weld center plate to truck frame (See Figure 2 & Additional Notes).
4. Position stub light bar weldment [Part No. 51H69] on truck frame. Stub light bar weldment should be as high and as far back as possible on the truck frame to avoid interference with the bumper and fenders. It may be necessary to modify the stub light bar weldment to avoid interference. Drill mounting holes as required and mount using fasteners provided (See Figure 3).
5. Attach the tail light module to the stub light bar weldments with the fasteners provided (See Figure 3).

6. Mount the identification light bar at top center of the center plate [Part No. 63H08] using the fasteners provided (See Figure 3).
7. Mount license lamp right of the license plate (See Fig. 2) using the fasteners provided (See Figure 3).




Figure 2

REAR LIGHT BAR ASSEMBLY

(LED-LB)

8. Mount junction box on the back left side of center plate (See Figure 2), using the fasteners provided (See Figure 3).
9. Route all wire harnesses into the junction box. Wire harnesses must enter the junction box through a compression fitting (based on the size of the wire harness, choose a compression fitting with an appropriately sized grommet). Make wiring connections in junction box with wire harness from truck cab as indicated on wiring diagram (See Figure 4).




Figure 3

MATERIAL LIST				
ITEM	QTY	P/N	DESCRIPTION	WT lb PER EA.
1	2	51H69	STUB LIGHT BAR WELDMENT	8.54
2	1	63H08	CENTER PLATE	27.33
3	6	00P44	3/8-16 x 1 1/2 HHCS	0.07
4	6	00P34	3/8-16 LOCKING HEX NUT	0.02
5	6	00771	Ø3/8 FLAT WASHER	0.01
6	4	01P18	5/8-11 x 3 HHCS	0.35
7	8	00P81	#8-32 x 1 RND HD SCR	-
8	8	00P82	#8-32 HEX NUT	-
9	8	00P83	#8 LOCK WASHER	-
10	1	40P32	LIC. LIGHT ASSEMBLY (WITHOUT HARNESS)	-
11	REF	40P34	LICENSE LAMP HARNESS	-
12	REF	40P35	ID LIGHT BAR RAIL	-
13	REF	40P37	ID LIGHT BAR HARNESS	-
14	REF	40P38	JUNCTION BOX ASSEMBLY	-
15	REF	40P39	LIGHT KIT ASSEMBLY	23.00
16	REF	40P40	RIGHT TAIL LIGHT MODULE w/ HARNESS	-
17	REF	40P41	LEFT TAIL LIGHT MODULE w/ HARNESS	-
18	REF	40P42	SIDE MARKER LAMP	-
19	REF	40P43	STOP, TURN, & TAIL LAMP	-
20	REF	40P44	LICENSE LAMP	-
21	REF	40P45	BACK-UP LAMP	-
22	REF	40P46	ID LIGHT BAR LAMP	-
TOTAL				68.74

Additional Notes:

1. Prior to any welding, consult the truck manufacturer for any special precautions that may need to be taken. Typically the batteries must be disconnected and the ground lead from the welder should be as close to the part being welded to avoid the possibility of arcing across bearings, gears, etc.

REAR LIGHT BAR ASSEMBLY (LED-LB)






Figure 4



SWAPLOADER[®]


U.S.A. LTD.



ROLLER & ROLLER MOUNT (10H90 & 10H91)

INSTALLATION INSTRUCTIONS

1. Review all directions and diagrams provided before starting the roller and roller mount installation.
2. Locate position for roller mount brackets [Part No. 32H03] between cross sills of the container. Rollers should be positioned as far back and as wide as possible for stability. For hoist and folding bumper clearance, do not place brackets any closer than 11" to the subframe longsill (See Fig.1). Also, the roller axle center line should be approximately 1-11/16" below the bottom of the subframe longsill for roller clearance (See Fig. 1).



ROLLER & ROLLER MOUNT (10H90 & 10H91)

INSTALLATION INSTRUCTIONS (continued)

3. Some modification to the roller mount bracket may be required for the roller mount to fit properly. If the existing container cross members are wider than 6", a fabricated support member of 1/2" plate or thicker will need to be added (See Fig. 2).
4. Once the mount brackets are located on the container, weld the roller mount brackets in place (See Fig. 1).
5. Install the roller [Part No. 10H12] between the brackets with the roller axle [Part No. 10H31] and the fasteners provided (See Fig. 3). Grease the rollers before use.




FIG. 2

MATERIAL LIST				
ITEM	QTY	P/N	DESCRIPTION	WT lb. PER EA.
1	4	32H03	ROLLER EAR	11.95
2	2	10H12	ROLLER WDMT.	39.78
3	2	10H31	ROLLER AXLE WDMT.	7.28
4	2	00P62	3/8-16 UNC X 1 BOLT	.05
5	2	90P03	1/8 NPT GREASE ZERK	.01
6	2	00755	3/8 DIA. LOCK WASHER	.01
7	2	00P36	3/8 DIA. WASHER H.T.	.10
TOTAL				142.26






FIG. 3



SWAPLOADER[®]

U.S.A. LTD.



TOOLBOX

Aluminum (10H92) / Steel (11H12)


INSTALLATION INSTRUCTIONS

1. Review all directions and diagrams provided before starting toolbox installation.
2. Position toolbox brackets [Part No. 10H88] on truck chassis.
(NOTE: toolbox has an envelope of 18"x18"x36". See Fig. 1 for hole dimensions.)
3. Mark position of mounting holes through brackets onto truck chassis. Remove brackets and drill 9/16" dia. holes.
4. Mount toolbox brackets using fasteners provided (See Fig. 1).
5. Position toolbox [Part No. 90P27 or 90P37] on brackets. (NOTE: toolbox hinge should be on the forward, bottom edge.)
6. Mark position of mounting holes through brackets onto toolbox. Remove toolbox and drill 9/16" dia. holes.
7. Mount toolbox to brackets using fasteners provided (See Fig. 1).

TOOLBOX

Aluminum (10H92) / Steel (11H12)

MATERIAL LIST				
ITEM	QTY	P/N	DESCRIPTION	WT lb. PER EA.
1	2	10H88	18" TOOLBOX BRACKET	11.34
2	2	22H71	TOOLBOX RUBBER SPACER (ALUMINUM TOOLBOX ONLY)	.27
3	1		18 X 18 X 36 TOOLBOX	
		90P27	ALUMINUM TOOLBOX	50.00
		90P37	STEEL TOOLBOX	72.00
4	8	00784	1/2 DIA. FLAT WASHER H.T.	.07
5	4	00P15	1/2-13 UNC X 1-3/4 HEX HEAD BOLT	.23
6	8	00P35	1/2-13 UNC METAL LOCKING NUT	.15
7	4	00P75	1/2-13 UNC X 1-1/2 SOCKET BUTTON HEAD BOLT	.12
8	4	00P76	1/2 DIA. NYLON FLAT WASHER (ALUMINUM TOOLBOX ONLY)	-
ALUMINUM TOOLBOX TOTAL				76.38
STEEL TOOLBOX TOTAL				97.84




OPERATION


OPERATING INSTRUCTIONS

LOADING A CONTAINER


1. Engage the P.T.O. (Refer to P.T.O. manual for operation).



2. Retract the jib (right control lever backward). Then, tilt the arm backward (left control lever backward).




3. Make sure the work area in front of the container is clear of people and obstacles. Move the truck backwards until the hook engages the curved lifting bar of the container. **NEVER EXTEND THE JIB** to reach the proper catching height, rather tilt the arm.






WARNING:


Make sure work area is clear of people and obstacles prior to dumping or unloading containers. SwapLoader strongly recommends that a back up alarm be installed on the truck chassis. The operation of the hook hoist is that the truck is backed up to the body to pick it up and so there is a potential pinch point between the body and the hook.



-
4. Cycle the arm forward (left control lever forward), making sure the curved lifting bar is securely attached to the hook. Release the brakes of the truck and steer to correctly align the truck with the container. Watch the container rails to see that they come to rest centered on the rear rollers. Do not extend the jib during lifting.



5. When the container is resting on the frame, move the jib forward all the way to ensure the container is held in the body locks (right control lever forward). Disengage the P.T.O.



DUMPING

1. Move the jib forward (right control forward) to ensure that the container is locked.
2. Extend the main lift cylinders (left control backward).




CAUTION:


DO NOT RETRACT THE JIB WHILE DUMPING. Retracting the jib during dumping may unlock the mechanical jib latches which could allow the container to crash down onto the hoist and/or abruptly unload.

PLACING A CONTAINER ON THE GROUND


1. Move the sliding jib all the way back (right control backward) until mechanical jib latches unlock.



2. Tilt the arm backwards (left control backward). When the container touches the ground, release the brakes to free the truck for forward movement caused by the container.



3. Rotate jib all the way till the container touches the ground. Pull away from container and rotate jib back into the transport position.



WARNING:


1. **DON'T OVER SPEED THE PUMP 1,500 RPM MAXIMUM.**
2. **DON'T DUMP, MOUNT OR DISMOUNT BODIES ON UNEVEN GROUND.**





WARNING (cont'd):


- 3. DON'T DRIVE WITH THE HOIST IN THE DUMP POSITION OR WITH THE HOOK TILTED BACK.**



OPERATING THE STABILIZER

If loading or unloading a heavy container that would cause the front end of the truck to lift off the ground, then a stabilizer should be utilized if the unit is equipped with one.

When *Loading a Container* the stabilizer should be lowered between steps 3 & 4, while when *Placing the Container on the Ground* the stabilizer should be lowered between steps 1 & 2 (see the previous operating instructions on pages 3-1 to 3-3).



To lower the stabilizer, push forward on the left control lever until the roller is all the way down.

When finished with loading or unloading the container the stabilizer roller should be raised prior to disengaging the P.T.O. To raise the stabilizer, push backward on the left control lever until the roller is all the way up.

CHANGING HOOK HEIGHT

54" to 61-3/4" Jib Height Adjustment Procedure:



CAUTION:


The following is the recommended procedure for changing hook heights on the adjustable jib from 54" to 61-3/4" heights. Failure to follow and adhere to this procedure may result in possible property damage and/or personal injury.




WARNING:

Make sure work area is clear of people and obstacles prior to changing the hook height on the adjustable jib.

1. With the telescopic arm in the transport position (as shown); remove the hitch pin from the lock pin. Then pull the lock pin loose from the jib arm.




2. Retract the jib (right control lever backward). See Fig. A (Pg. 3-1).




Changing Hook Height from 54" to 61-3/4" Continued:

3. Tilt the telescopic arm rearward (left control lever backward). See Fig. A (Pg. 3-1).




4. Continue to tilt telescopic arm rearward until the dump cylinders are fully extended. Replace lock pin and secure with hitch pin.



WARNING:

Do not remove lock pin on the adjustable jib while jib is in the 54" hook position and the telescopic arm is tilted rearward (as shown). Possible property damage and/or personal injury may result.



CHANGING HOOK HEIGHTS

61-3/4" to 54" Jib Height Adjustment Procedure:



CAUTION:


The following is the recommended procedure for changing hook heights on the adjustable jib from 61-3/4" to 54" heights. Failure to follow and adhere to this procedure may result in possible property damage and/or personal injury.




WARNING:

Make sure work area is clear of people and obstacles prior to changing the hook height on the adjustable

1. With the telescopic arm in full load/unload position (as shown); remove the hitch pin from the lock pin. Then pull the lock pin loose from the jib arm.




2. Tilt the telescopic arm toward the cab (left control lever forward). See Fig. A (Pg. 3-1).




Changing Hook Height from 61-3/4" to 54" Continued:

3. Extend the jib toward the cab (right control lever forward). See Fig. A (Pg. 3-1).




4. With the telescopic jib fully extended in the transport position (as shown); replace the lock pin and secure with hitch pin.



WARNING:

Do not remove lock pin on the adjustable jib while jib is up in the 61-3/4" hook position and telescopic arm in transport position (as shown). Possible property damage and/or personal injury may result.




Rear Roller Spacing Adjustment Instructions for SwapLoader Hook-lift Hoists

INTRODUCTION:

Industry standard for the outside rail width dimension on subframe longsills is either 40-1/2" or 41-5/8" (see illustration below). For most 35-5/8" hook height (100 series) and 53-7/8" hook height (200/300 series) subframes the outside width dimension of the longsill rails is 41-5/8". For most 61-3/4" hook height (400 series) subframes the outside width dimension of the longsill rails is 40-1/2".

From this point forward we will refer to the rear rollers setup for 40-1/2" outside width as 'narrow spacing' and rear rollers setup for 41-5/8" outside width as 'wide spacing'.




HOIST STANDARD:

All SwapLoader hooklift hoists are made so that the rear rollers can be spaced at either the wide spacing or narrow spacing depending on the subframe design (the only exception is the SL-105 which can only accommodate a 'wide spacing' or 41-5/8" outside width). Unless instructed otherwise SwapLoader will ship hoists with the rear rollers setup per the previously discussed industry standard for a given hook height of subframe, or as detailed in the chart below.

Subframe Hook Height (series)	Hoist Models	Standard Roller Spacing
35-5/8" (100 series)	SL-105, SL-145, SL-180 & SL-185	41-5/8" (wide width)
53-7/8" (200 & 300 series)	SL-220, SL-222, SL-240 & SL-2418	41-5/8" (wide width)
61-3/4" (400 series)	SL-330, SL-375, SL-400, SL-405, SL-406, SL-412, SL-505, SL-545 & SL-650	40-1/2" (narrow width)

Rear Roller Spacing Adjustment Instructions (continued)



NARROW TO WIDE ROLLER SPACING ADJUSTMENT:

To change a hoist from the narrow roller spacing to a wide roller spacing follow these instructions:

1. Loosen and remove the retaining bolts, washers and roller retainer.
2. Remove the roller spacer and rear roller from the hoist roller shaft.
3. Place the roller spacer on first; then place the rear roller back on the roller shaft.
4. Replace and tighten the retaining bolts, retaining washer and roller retainer.

WIDE TO NARROW ROLLER SPACING ADJUSTMENT:

To change a hoist from the wide roller spacing to a narrow roller spacing follow these instructions:


1. Loosen and remove the retaining bolts, washers and roller retainer.
2. Remove the rear roller and roller spacer from the hoist roller shaft.
3. Place the rear roller on first; then place the roller spacer back on the roller shaft.
4. Replace and tighten the retaining bolts, washers and roller retainer.

MAINTENANCE

MAINTENANCE INSTRUCTIONS

WEEKLY SERVICE - (50 OPERATIONS)

1. Lubricate with grease (Refer to Lubrication Diagram)
 - Lifting hook on jib (if operating the adjustable jib be sure to rotate and grease hook).
 - Jib slide - top, bottom, and side guides.
2. Check hydraulic oil level. With the hoist in the transport position (lift cylinders retracted and jib cylinder extended – see diagram on front cover) the oil level in the tank should read approximately one inch below the top of the glass sight on the temperature/sight gauge (see diagram ➔).
3. Check hydraulic hose and fittings for leaks. Also check hydraulic hose for wear. Repair and/or retighten as necessary.




MONTHLY SERVICE - (200 OPERATIONS)

1. Lubricate with grease (Refer to Lubrication Diagram)
 - Fittings on lift cylinders (quantity: 4)
 - Front pins on rear pivot joint weldment (quantity: 2)
 - Fittings on rear pivot pins and rollers (quantity: 4)
2. Check all bolts and retighten as required.
3. Check adjustments on mast lock (safety latch) mechanism. Refer to the Mast Lock Inspection & Adjustment Instructions on page 4-7 of the maintenance section.
4. Check adjustments on the jib lockout valve. Refer to the Jib Lockout Valve Inspection & Adjustment Instructions on page 4-9 of the maintenance section.

YEARLY SERVICE

1. Check for proper gapping on outer tube clamp assembly. Refer to the Outer Tube Clamp Inspection & Adjustment Instructions on page 4-13 of the maintenance section.
2. Change hydraulic oil, replace hydraulic filter element, and wash out suction strainer.
3. Check main relief valve setting. Refer to the Pressure Check Instructions on page 4-11 of the maintenance section. (Pressure should be 3,500 PSI minimum).



HYDRAULIC OIL SPECIFICATION & INTERCHANGE CHART

Select an ISO grade of Premium Anti-Wear Hydraulic Oil that is optimum for your location.

HYDRAULIC OIL SELECTION CHART

ISO Grade	Ambient Temperature Range		Viscosity
	°F	°C	SUS @ 100 °F
32	-10 to 85	-23 to 29	150-170
46	10 to 110	-12 to 43	195-240

NOTE 1: Always consult your local hydraulic oil supplier for more information.

NOTE 2: Use caution when operating at or beyond the recommended temperature extremes.

NOTE 3: Do not operate the hooklift hoist when hydraulic oil temperature on tank gauge exceeds 160 °F (71 °C) as damage to hydraulic components can occur.

ISO Grade 32

Company Name	Brand Name & Grade
Castrol (BP)	Paradene 32AW
CITGO	A/W 32
Exxon	Nuto H 32
Mobil	DTE 24 (DTE 13)
Shell	Tellus 32
SUNOCO	Sun Vis 706 (816 WR)

ISO Grade 46

Company Name	Brand Name & Grade
Castrol (BP)	Paradene 46AW
CITGO	A/W 46
Exxon	Nuto H 46
Mobil	DTE 25 (DTE 15)
Shell	Tellus 46
SUNOCO	Sun Vis 747 (821 WR)

HYDRAULIC FILTER ELEMENT SPECIFICATIONS & INTERCHANGE CHART

Element Size:	5.10 ϕ x 10.9"
Mounting Thread:	1 1/2-16 UN-2B
Filtration Rating:	10 micron (Nominal)
Flow Rating:	60 GPM

Company Name	Filter Part Number
Baldwin	BT-388-10
Can Flo	RSE60-10N
Case	D-130046
Donaldson	HSM6047
Fleetguard	R750-H-0825A
FPC	HF6711

Company Name	Filter Part Number
Hydac	0180MA010P
LHA	SPE60-10
Norman	610
Parker	927736
Wix	51860
Zinga *	LE-10

* Brand of Element supplied from factory on hoist.

MAST LOCK INSPECTION & ADJUSTMENT INSTRUCTIONS


All SwapLoader hook-lift hoists come with a mast lock (safety latch) assembly that is located on the bottom side of the outer tube. When the jib is extended the mast lock then engages the latch bars (forks) on the pivot joint, making the jib, outer tube, and pivot joint into a continuous member for raising the container or body up into a dump mode.

With the jib fully retracted the mast lock then disengages the latch bars on the pivot joint allowing the hook-lift to enter into the mount-dismount cycle by pivoting around the front pins of the pivot joint. A properly adjusted mast lock will function smoothly and clear the latch bars on the pivot joint approximately a $\frac{1}{4}$ " (see illustrations below).

INSPECTION

The mast lock assembly comes adjusted from the factory and should provide years of trouble free operation, however there may come a time when an adjustment may be required. Prior to making any adjustments, SwapLoader recommends that you begin with inspecting all mast lock components for damage or wear (see illustrations below).

First inspect the adjustment tube and bolt on the jib; make sure nothing is missing or bent. Next, inspect the release lever and connection bar on the outer tube; look for any missing or bent components such as ears or pins. Finally, inspect the safety latch tube and inner tube (see illustration below); again make sure there are no missing or bent components such as ears, pins, or latches. Repair or replace any missing or bent components prior to making any adjustment to the mast lock assembly; refer to the mast lock (safety latch) assembly drawing for proper part numbers and identification of the components (See Drawing No. 44H33 in the Part List pages of the manual).



ADJUSTMENT


If after inspecting all mast lock components and making any necessary repairs the gap between the mast lock and latch bars on the pivot joint is still incorrect, then an adjustment will need to be made. Please complete the following steps:

1. Retract the telescopic jib until the cylinder completely bottoms out (fully retracted).
2. Inspect the gap between the mast lock latch and the latch bar on the pivot joint. Look for a clearance of approximately 1/4" (if not proceed to steps 3-5).
3. Loosen the jam nut on the adjustment bolt.
4. Turn the adjustment bolt; counter-clockwise to increase the gap or clockwise to decrease the gap.
5. Once the 1/4" clearance is achieved, then tighten the jam nut. Make sure to hold the adjustment bolt from turning when tightening the jam nut.

Please contact your SwapLoader Distributor or SwapLoader USA should you have any questions regarding this procedure.

JIB LOCKOUT VALVE INSPECTION & ADJUSTMENT INSTRUCTIONS


All SwapLoader hook-lift hoists have a jib lockout valve (see illustration below) to prevent accidental operation of the telescopic jib, while the hoist is up in a dump mode. Because the jib lockout valve can block the flow of hydraulic oil to the jib cylinder, should the valve come out of adjustment the telescopic jib may experience a reduction in extension or retraction speed to the point of stalling out.



INSPECTION

When a noticeable loss in extension or retraction speed of the telescopic jib is experienced, the first step should be to inspect the jib lockout valve and valve mount ramp to ensure that they are adjusted properly and in good working order. The jib lockout valve is located on the inside rail of the hoist mainframe approximately two-thirds of the way back on the driver side of the hoist (see Drawing No. 44H25 in the Part List pages of the manual). Visually inspect the jib lockout valve roller and the condition of the valve ramp on the hoist pivot joint without a container on the hoist (see illustration on the next page); this is most easily performed with the hoist back in a dismount mode. If either part shows signs of wear or damage then replace or repair as needed.

With the jib lockout valve roller and valve ramp in good condition the next step is to check that the valve is positioned correctly with respect to the valve ramp. While looking at the roller end of the jib lockout valve, notice that the roller moves in and out of an end cap. With the hoist pivot joint in the down position, or horizontal to the hoist mainframe, the valve ramp should be in contact with the jib lockout valve roller. The roller should be depressed by the valve ramp so that 1/8" to 3/16" of the roller is exposed from the end cap (see illustrations above and on next page).



ADJUSTMENT

Should the jib lockout valve need adjustment the first step will be to loosen the mount bracket screws (see illustration above). Reposition the jib lockout valve with respect to the valve ramp by turning the adjustment screw on the valve mount bracket as follows:

Clockwise Adjustment – Moves the jib lockout valve closer to the valve ramp

Counter-Clockwise Adjustment – Moves the jib lockout valve away from the valve ramp

Once the valve has been moved back into proper adjustment, then tighten up the mount bracket screws.


PART NUMBER & SPECIFICATION

SwapLoader Pt. No.	Work Port Size	Spool Type	Pressure (Maximum)	Flow Rate (Maximum)
21P29	7/8-14 ORB (SAE 10)	2-Way, 2-Position N.C.	4,600 PSI (Nominal)	24 GPM (Nominal)

Please contact your SwapLoader Distributor or SwapLoader USA should you have any questions regarding this procedure.

PRESSURE CHECK INSTRUCTIONS


When performing a pressure check on a SwapLoader hook-lift hoist, we recommend that you use a calibrated pressure gauge that reads pressures up to 3,500 PSI (a 0 to 5,000 PSI range gauge is recommended). As a minimum, the gauge should have 100 PSI graduation marks (50 PSI is preferred), and a 3 inch diameter dial size (4 inch dial is preferred). The pressure gauge should be outfitted with a female JIC #4 hydraulic adapter; preferably located at the end of a 3/8 inch diameter high pressure hydraulic hose that is 2 to 3 foot in length (see illustration below).



Should you not be able to source a hydraulic gauge locally, SwapLoader can provide one at a reasonable cost (Hyd. Pressure Gauge & Hose Ass'y – [Part No. 22P10](#)).


PRESSURE CHECK STEPS

1. Locate the 90° male JIC #4 hydraulic adapter (SWL #10P37) found on the top of the hoist hydraulic control valve (see illustration below).




This 90° male #4 JIC hydraulic adapter is supplied by SwapLoader, and should be installed in the hydraulic control valve at the time of the hoist installation (see the hoist parts & operations manual).

2. Remove the female JIC #4 cap from the male JIC #4 adapter and attach the pressure gauge to the hydraulic control valve (see illustration below).



3. Start the truck and engage the P.T.O.
4. Push the lift (dump) circuit lever forward until the lift (dump) cylinders bottom out (see illustration below). Continue to push the lever forward until steps 5-6 are complete.



5. Check the gauge for the maximum developed system pressure. The SL-520 should have a reading of 3,500 PSI.
6. With the pressure check complete; release all functions and disengage the P.T.O.


Please contact your SwapLoader Distributor or SwapLoader USA should you have any questions regarding this procedure.

OUTER TUBE CLAMP ASSEMBLY INSPECTION INSTRUCTIONS


All SwapLoader hooklift hoists come equipped with an outer tube clamp assembly located on the bottom of the outer tube at the opening where the jib telescopes in and out (see illustration below). On SwapLoader Heavy Duty Series hoist models the outer clamp assembly is fixed in height.

INSPECTION

The illustration below is a typical hoist clamp assembly for the SwapLoader Heavy Duty Series hoist models. For optimum performance out of your SwapLoader SL-520 hooklift the gap between the top of the jib horizontal tube and the top inside surface of the outer tube should be kept between 1/16" to 1/8" (see Section View A-A below). When a gap greater than 1/8" exists, since the clamp assembly has a fixed elevation, inspect the clamp liner, clamp plate, and fasteners for excessive wear or damage (see Section View A-A below). Replace parts as needed to bring the outer tube clamp assembly back to recommended specifications (see Drawing No. 44H03 in the Parts List pages of the manual).




PARTS LIST



SL-520 BASE ASSEMBLY W/ ADJ. JIB 44H23

PARTS PER 44H23				
ITEM	PART #	QTY	DESCRIPTION	WT-lb/ea
1	44H16	1	DUAL BODY LOCK WELDMENT	153.79
2	44H25	1	MAIN FRAME SUB-ASSEMBLY	3284.42
3	44H28	1	OUTER TUBE SUB-ASSEMBLY	1323.21
4	44H35	1	ADJUSTABLE JIB ASSEMBLY	971.30
5	44H41	1	PIVOT JOINT SUB-ASSEMBLY	961.50
6	89H06	2	BODY LOCK MOUNT SHIM	4.39
7	91H21	1	HYD SUB-ASSY BASE - NOT SHOWN	44.09
8	00769	4	3/4" LOCK WASHER	0.01
9	00P17	4	3/4-10 UNC HEX NUT	0.13
10	00P93	4	3/4-10 UNC x 2 1/2" HHCS (GR. 8)	0.42
11	91P13	1	SL-520 SERIAL TAG	0.02
TOTAL				6645.99





An IFCO COMPANY

SWAPLOADER


U.S.A. LTD


BASE HOIST ASSEMBLY w/ ADJ. JIB
SL-520
44H23




SL-520 BASE ASSEMBLY W/ FIXED JIB 44H24

PARTS PER 44H24				
ITEM	PART #	QTY	DESCRIPTION	WT-lb/ea
1	44H16	1	DUAL BODY LOCK WELDMENT	153.79
2	44H25	1	MAIN FRAME SUB-ASSEMBLY	3284.42
3	44H28	1	OUTER TUBE SUB-ASSEMBLY	1323.21
4	44H38	1	FIXED JIB ASSEMBLY	730.76
5	44H41	1	PIVOT JOINT SUB-ASSEMBLY	961.50
6	89H06	2	BODY LOCK MOUNT SHIM	4.39
7	91H21	1	HYD SUB ASSY BASE - NOT SHOWN	44.09
8	00769	4	3/4" LOCK WASHER	0.01
9	00P17	4	3/4-10 UNC HEX NUT	0.13
10	00P93	4	3/4-10 UNC x 2 1/2" HHCS (GR. 8)	0.42
11	91P13	1	SL-520 SERIAL TAG	0.02
TOTAL				6473.21





 An IRACO Company SWAPLOADER U.S.A. LTD	
BASE HOIST ASSEMBLY w/ FIXED JIB	
SL-520	
44H24	

CYLINDER SERVICE PARTS LIST	
PART #	DESCRIPTION
21P79	SEAL KIT
21P17	COUNTERBALANCE VALVE





SECTION A-A



OUTER TUBE SUB-ASSEMBLY 44H28


PARTS PER 44H28 SUB-ASSEMBLY				
ITEM	QTY	PART #	DESCRIPTION	WT.-lb./ea.
1	1	40H44	CLAMP PLATE WDMT	30.00
2	1	40H69	Ø1 3/4" CYLINDER PIN WDMT	6.99
3	1	44H29	OUTER TUBE WELDMENT	829.37
4	1	44H33	PIVOT LOCK SUB-ASSEMBLY	92.64
5	4	60H11	WEAR PAD	0.21
6	2	80H35	CLAMP LINER	0.28
7	2	81H20	CYLINDER PIN CAP	0.41
8	1	82H50	CYLINDER PIN Ø1 3/4"	6.24
9	2	82H51	CYLINDER RETAINER	1.64
10	1	87H52	CLAMP PLATE SPACER	4.04
11	8	00P31	1/2-13 UNC x 1 1/4" HHCS	0.10
12	8	00P58	3/8-16 UNC x 1 1/2" FHS	0.05
13	6	00P69	5/8-11 UNC x 2" HHCS	0.23
14	16	00P79	3/8-16 UNC x 3/4" FHS	0.03
15	2	00P95	5/8-11 UNC x 1 1/4" FHSS	0.11
16	1	00P97	EXT RET RING FOR 1 3/4Ø	0.01
17	8	01P30	Ø1/2" LOCK WASHER	0.01
18	1	21P76	HYD. CYLINDER 4 1/2" x 52"	344.98
19	6	00767	Ø5/8" LOCK WASHER	0.01
TOTAL				1322.91




 SWAPLOADER <small>An IFCO Company U.S.A. LTD.</small>	
OUTER TUBE SUB-ASSEMBLY	
SL-520	
44H28	

CYLINDER SERVICE PARTS LIST	
PART #	DESCRIPTION
21P17	COUNTERBALANCE VALVE CARTRIDGE
22P16	Ø3 1/2" SPERICAL BEARING
22P17	Ø5 1/2" SNAP RING, INT
22P59	SEAL KIT
22P61	HYD RETURN LINE



PARTS PER 44H25 SUB-ASSEMBLY				
ITEM	PART #	QTY	DESCRIPTION	WT-lb/ea
1	40H83	2	MAIN FRAME PIN WELDMENT	18.08
2	41H81	2	FRONT GUIDE SHIM WELDMENT	4.49
3	42H49	1	JIB LOCKOUT VALVE MOUNT	2.61
4	44H26	1	MAIN FRAME WELDMENT	1626.98
5	00755	46	3/8" LOCK WASHER	0.00
6	00P14	44	3/8-16 UNC HEX NUT (GR. 8)	0.02
7	00P32	2	3/8-16 UNC x 1 1/4" SHCS	0.05
8	00P44	4	3/8-16 UNC x 1 1/2" BOLT (GR. 8)	0.06
9	00P56	2	5/8-11 UNC x 1 1/2" BOLT	0.19
10	00P68	40	3/8-16 UNC x 1 1/4" FLT HD SCR (SS)	0.04
11	01P31	2	5/8Ø DISC-LOCK WASHER	0.03
12	01P45	1	3/8-16 UNC SQ. HEAD SET SCREW	0.06
13	22P53	2	7" x 82" STROKE x 3 1/4" HYD CYL	800.00
14	90P71	10	12" WEAR PAD	0.63
TOTAL				3292.49




SECTION A-A



DETAIL B



MAIN FRAME SUB-ASSEMBLY 44H25




An IPG COMPANY

SWAPLOADER
U.S.A. LTD


MAIN FRAME SUB-ASSEMBLY

SL-520


44H25




PARTS PER 44H33 SUB-ASSEMBLY				
ITEM	QTY	PART #	DESCRIPTION	WT-lb./ea.
1	2	40H38	TAKE UP WELDMENT	0.30
2	1	40H42	CONNECTION BAR PIN	0.36
3	1	44H06	PIVOT LOCK WELDMENT	42.32
4	1	44H15	PIVOT LOCK CONNECTOR SUB-WDMT	10.19
5	1	44H34	CONNECTION BAR WELDMENT	4.57
6	2	81H51	RELEASE LEVER	8.42
7	4	87H85	PIVOT LOCK SPACER	1.58
8	1	88H41	PIVOT LOCK CONNECTOR	7.37
9	4	00769	3/4" LOCK WASHER	0.01
10	3	00772	1/2" STD. WASHER	0.04
11	4	00P02	1/2-13 UNC HEX NUT	0.04
12	7	00P26	1/8" x 1" COTTER PIN	0.01
13	2	00P28	EXT RET RING FOR 3/4Ø	0.01
14	4	00P94	3/8" x 1 1/2" CLEVIS PIN	0.05
15	4	01P53	3/4-10 UNC x 4 1/4" HHCS	0.64
16	2	90P04	7/8" x 6" SPRING	0.47
TOTAL				92.40




PIVOT LOCK SUB-ASSEMBLY 44H33





ADJUSTABLE JIB ASSEMBLY 44H35

PARTS PER 44H35 ASSEMBLY				
ITEM	PART #	QTY	DESCRIPTION	WT-lb/ea
1	43H10	1	PIVOT PIN WELDMENT	12.37
2	43H11	1	LOCK PIN WELDMENT	9.68
3	44H36	1	ADJUSTABLE JIB WELDMENT	794.38
4	60H11	2	WEAR PAD	0.21
5	62H11	1	COVER PLATE	0.92
6	86H95	1	HOOK	150.70
7	86H98	1	LOCK TUBE	1.25
8	53586	1	3/8" x 2 1/2" SAFETY SNAP PIN	0.14
9	00755	2	3/8" LOCK WASHER	0.01
10	00P03	2	3/8-16 UNC x 3/4" HHCS (GR. 8)	0.04
11	00P24	2	5/8-11 UNC HEX NUT (GR. 8)	0.08
12	00P34	1	3/8-16 UNC LOCKING HEX NUT	0.02
13	00P58	8	3/8-16 UNC x 1 1/2" F.H. SCREW	0.05
14	00P99	1	3/8-16 UNC x 4" HHCS	0.14
15	01P18	2	5/8-11 UNC x 3" HHCS (GR. 8)	0.32
16	90P03	1	1/8" NPT ZERK	0.02
17	90P94	2	ADJ JIB OPERATION DECAL	0.01
TOTAL				969.34




An EPO Company

SWAPLOADER
U.S.A. LTD

ADJUSTABLE JIB SUB-ASSEMBLY


SL-520

44H35 - REV A



FIXED JIB ASSEMBLY (44H38)

PARTS PER 44H38 ASSEMBLY				
ITEM	PART #	QTY	DESCRIPTION	WT-lb/ea
1	44H39	1	FIXED JIB WELDMENT	693.96
2	60H11	2	WEAR PAD	0.21
3	62H11	1	COVER PLATE	0.92
4	00755	2	3/8" LOCK WASHER	0.00
5	00P03	2	3/8-16 UNC x 3/4" HHCS (GR. 8)	0.04
6	00P24	2	5/8-11 UNC HEX NUT (GR. 8)	0.08
7	00P79	8	3/8-16 UNC x 3/4" FHS	0.03
8	01P18	2	5/8-11 UNC x 3" HHCS (GR. 8)	0.32
TOTAL				728.00



SWAPLOADER
U.S.A. LTD.

FIXED JIB SUB-ASSEMBLY

SL-520

44H38 - REV A


DISC-LOCK WASHER TORQUE SPECS	
BOLT SIZE	SAE GR 8 ASSY TORQUE (FT-LBS)
3/8	50
7/16	80
1/2	120
5/8	230
3/4	380
7/8	400
1	400

NOTE:
LUBRICATE BOLT THREADS BEFORE TORQUING THE ASSEMBLY


SERVICE PARTS LIST FOR 40H91 & 42H30	
PART #	DESCRIPTION
50P20	BRONZE BEARING

SERVICE PARTS LIST FOR 40H93	
PART #	DESCRIPTION
50P21	BRONZE BEARING




PARTS PER 44H11				
ITEM	PART #	QTY	DESCRIPTION	MASS
1	40H84	2	MAIN PIVOT PIN WELDMENT	16.99
2	40H93	2	ROLLER ASSEMBLY	41.78
3	43H79	2	PIN CAP WELDMENT	1.42
4	43H80	2	PIVOT PIN WELDMENT	11.01
5	44H42	1	PIVOT JOINT WELDMENT	812.36
6	83H10	2	ROLLER SPACER	0.64
7	83H11	2	ROLLER RETAINER	1.61
8	00P01	6	1/2-13 UNC x 1 1/2" BOLT	0.11
9	00P56	2	5/8-11 UNC x 1 1/2" BOLT	0.19
10	01P30	6	Ø1/2" LOCK WASHER	0.01
11	01P31	2	5/8Ø DISC-LOCK WASHER	0.03
12	01P32	2	Ø3/4" DISC-LOCK WASHER	0.06
13	01P52	2	3/4-10 UNC x 2" SHSC	0.38
14	90P03	6	1/8" NPT ZERK	0.02
TOTAL				918.28




PIVOT JOINT SUB-ASSEMBLY 44H41




 SWAPLOADER <small>U.S.A. LTD</small>	An IFCO COMPANY	
	PIVOT JOINT SUB-ASSEMBLY	
	SL-520	
	44H41	





PARTS PER 44H44				
ITEM	PART #	QTY	DESCRIPTION	WT-lb/ea
1	40H34	8	SPRING CAP	0.38
2	44H18	4	CHASSIS MNT BRKT, SHORT	3.69
3	44H19	4	CHASSIS MNT BRKT, LONG	5.56
4	44H45	1	PARTS & OP MANUAL	0.01
5	44H46	1	DECAL ASSEMBLY	0.01
6	88H57	6	FRONT BRACKET	5.54
7	00755	7	3/8" LOCK WASHER	0.00
8	00785	46	5/8" H.T. WASHER	0.05
9	00786	12	3/4" H.T. WASHER	0.06
10	00P14	7	3/8-16 HEX NUT	0.02
11	00P44	4	3/8-16 x 1 1/2" BOLT	0.06
12	00P55	46	5/8-11 LOCKING NUT	0.08
13	00P69	38	5/8-11 x 2" HHCS (GR. 8)	0.23
14	00P72	12	3/4-10 LOCKING HEX NUT	0.13
15	00P92	8	5/8-11 x 4" HHCS	0.41
16	00P99	3	3/8-16 x 4" HHCS	0.14
17	01P54	12	3/4-10 x 2" CARRIAGE BOLT	0.36
18	10P63	2	5/16-18 x 1 3/4" HEX BOLT	0.04
19	10P64	2	COVER PLATE	0.10
20	10P65	2	HOSE CLAMP	0.07
21	90P30	8	SPRING CYLINDER	0.01
				116.56






PARTS PER 91H19				
ITEM	QTY	PART#	DESCRIPTION	REMARKS
1	1	10P31	ADP, HYD M/JC / ORB 45°	6802-16
2	1	11P71	HOSE 1 1/2 LP x 120	
3	1	11P74	ADP, HYD M/JC / ORB	6400-16-12
4	2	11P77	T-BOLT CLAMP, Ø2"	TBC-200
5	2	11P95	ADP, HYD HOSE INS / MP	STC-20
6	1	12P48	ADP, HYD MP / FP	2 x 1 1/2


HYD SUB-ASS'Y - PUMP CIRCUIT
SL-518/520
91H19



PARTS PER 91H21				
ITEM	QTY.	PART #	DESCRIPTION	WT-lb/eq.
1	2	10P90	ADP, HYD MJIC/ORB	0.30
2	1	11P51	HOSE ASS'Y 3/4 V.H.P. x 23	2.00
3	2	11P58	HOSE ASS'Y 3/4 V.H.P. x 51	4.03
4	1	11P59	HOSE ASS'Y 3/4 V.H.P. x24	2.07
5	2	11P61	ADP, HYD MJIC BHD TEE	0.40
6	2	11P64	ADP, HYD MJIC/ORB	0.30
7	2	11P65	ADP, HYD JMJC/FMJIC SVL 90°	0.40
8	2	11P66	ADP, HYD MJIC BHD	0.40
9	1	11P91	HOSE ASS'Y 3/4 V.H.P. x 21	1.85
10	5	11P94	ADP, HYD FMJIC/MJIC SVL 45°	0.75
11	2	12P91	ADP, HYD MJIC/ORB 90°	0.40
12	1	21P29	HYD VALVE	4.20
13	4	13P16	ADP, HYD MJIC CAP	0.18
14	1	13P26	HOSE ASS'Y 3/4 V.H.P. x 132	9.93
15	1	13P27	HOSE ASS'Y 3/4 V.H.P. x 157	11.81

SWAPLOADER™ U.S.A. LTD.
HYD SUB-ASSY - BASE CYLINDER CIRCUIT
SL-520
91H21




PARTS PER 91H26				
ITEM	QTY.	PART #	DESCRIPTION	WT-lb/ea.
1	2	10P36	ADP, HYD MJC/ORB 90°	0.40
2	1	10P37	ADP, HYD MJC/MP 90°	0.30
3	1	10P38	ADP, HYD FMJC CAP	0.10
4	2	10P78	T-BOLT CLAMP, Ø1 3/4"	0.15
5	1	11P56	HOSE ASS'Y 3/4 H.P. x 28	2.36
6	1	11P57	HOSE ASS'Y 3/4 H.P. x 33	2.72
7	2	11P62	ADP, HYD MJC/ORB LL 90°	0.40
8	2	11P65	ADP, HYD MJC/FMJC SVL 90°	0.40
9	1	11P78	ADP, HYD MP/MP	0.70
10	1	12P25	ADP, HYD HOSE INS/MP	0.60
11	1	12P27	ADP, HYD HOSE INS/ORB 90°	0.70
12	1	12P33	HOSE 1 1/4 LP x 36	2.37
13	1	13P30	HYD TUBING - REAR LOWER	7.91
14	1	13P31	HYD TUBING - REAR UPPER	8.29
15	1	20P61	HYD FILTER	4.50
16	1	20P64	FILTER INDICATOR GAUGE	-
17	1	20P86	HYD TANK - 30 GAL	73.00
TOTAL				106.25

SHOP NOTES:

1. HYD TANK ASS'Y CONSISTS OF: TANK WELDMENT, TANK MOUNTED STRAINER, SIGHT GAUGE, FILLER/BREATHER CAP, MAGNETIC DRAIN PLUG, AND PORT PLUGS.

NO.		DATE	BY
REVISION	DATE	DATE	BY
<p>1. document and its contents are proprietary and confidential. It is intended only to be used by employees of EPCO or its affiliates. DO NOT REPRODUCE.</p>			
<p>SWAPLOADER USA, LTD.</p>			
<p>HYD SUB-ASS'Y CHASSIS TANK CIRCUIT</p>			
DESIGNED BY	CHECKED BY	DATE	
MCP	ELC	08/08/16	
DRAWING NO.	MODEL NO.	REV	
91H26	SL-520		

OPTIONS



NOTE:

1. FITTINGS AND TUBING SHOWN ARE PART OF THE 12P94 AIR LINE KIT.
2. THE 12P94 AIR LINE KIT CONTAINS FITTINGS FOR MULTIPLE PLUMBING CONFIGURATIONS AND NOT ALL FITTINGS MAY BE UTILIZED.




AIR CIRCUIT, CONTROL VALVE - 3 SECTION

SL-518/520/650

90H45 ~ REV B

SERVICE PARTS LIST FOR 20P59	
P/N	DESCRIPTION
21P18	HYDRAULIC RELIEF VALVE CARTRIDGE (3,500 PSI)



PARTS LIST					
ITEM	QTY	P/N	DESCRIPTION	WT-lb/ea	REMARKS
1	ONE	40H58	VALVE MOUNT BRACKET	14.15	
2	ONE	20P73	CONTROL HANDLE ASS'Y	2.40	
3	ONE	21P88	HYD CONTROL VALVE ASS'Y	58.00	
4	ONE	12P94	AIR LINE KIT	1.40	
5	ONE	51H37	AIR CONTROL CONSOLE ASS'Y	6.96	
6	3	20P71	HYD VALVE SECTION AIR SHIFT KIT	1.50	
7	ONE	20P74	AIR PRESSURE PROTECTION VALVE	0.59	WM778A
				88.00	TOTAL

- NOTE:
- 20P71 AIR SHIFT KIT TO BE INSTALLED ON HYD CONTROL VALVE BY HOIST INSTALLER. REFERENCE INSTALLATION INSTRUCTIONS INCLUDED WITH THE AIR SHIFT KIT.
 - SEE DRAWING 90H45 FOR AIR SHIFT KIT PLUMBING DIAGRAM.


SWAPLOADER™
U.S.A. LTD.

AIR CONTROL ASS'Y - 3 SECTION


SL-518/520/650

90H48 ~ REV C

SERVICE PARTS LIST FOR 20P59	
P/N	DESCRIPTION
21P18	HYDRAULIC RELIEF VALVE CARTRIDGE (3,500 PSI)



PARTS LIST					
ITEM	QTY	P/N	DESCRIPTION	WT-lb/ea	REMARKS
1	ONE	40H58	VALVE MOUNT BRACKET WDMT	14.15	
2	3	20P08	REMOTE VALVE CONTROL HANDLE	2.80	
3	ONE	20P78	CONTROL HANDLE MOUNT CONSOLE	4.75	
4	3	20P40	CONTROL CABLE 96" LG	2.00	
5	3	20P65	BONNET CONNECTION KIT	0.50	
6	ONE	21P88	HYD VALVE ASS'Y, 3 SECTION	58.00	
				92.80	TOTAL



 **SWAPLOADER™**
U.S.A. LTD.

MANUAL CONTROL ASS'Y - 3 SECTION

SL-518/520/650


90H50 ~ REV B

PARTS LIST											
ITEM	QTY	P/N	DESCRIPTION	WT-lb/ea	REMARKS	ITEM	QTY	P/N	DESCRIPTION	WT-lb/ea	REMARKS
1	ONE	42H63	STABILIZER MOUNT	180.02		10	ONE	21P84	HYDRAULIC CYLINDER 3ø x 6	35.00	
2	ONE	42H64	STABILIZER ARM	64.65		11	ONE	90H83	STABILIZER HYDRAULIC CIRCUIT	21.20	NOT SHOWN
3	ONE	42H65	STABILIZER ROLLER	78.10		12	4	00755	3/8ø LOCK WASHER	0.01	GR 8
4	ONE	86H65	UPPER CYLINDER PIN	1.55		13	4	00787	1ø FLAT WASHER H.T.	0.13	F-436
5	ONE	86H66	LOWER CYLINDER PIN	0.88		14	4	00P03	3/8-16 x 3/4 HHCS	0.04	GR 8
6	ONE	86H67	UPPER SHAFT	39.38		15	ONE	00P55	5/8-11 LOCKING HEX NUT	0.11	GR 8
7	ONE	86H68	LOWER SHAFT	26.20		16	4	00P98	5/32ø x 1 1/2 COTTER PIN	0.01	
8	2	86H69	SHAFT RETAINER	0.71		17	ONE	01P39	5/8-11 x 4 1/2 HHCS	0.49	GR 8
9	2	86H70	MOUNT GUSSET	3.74		18	4	90P03	1/8 NPT ZERK STR	0.01	
										457.28	TOTAL




SWAPLOADER™
U.S.A. LTD.

STABILIZER
FINAL ASSEMBLY
42H62



PARTS LIST					
ITEM	QTY	P/N	DESCRIPTION	WT-lb/ea	REMARKS
1	ONE	10P44	HYD ADP, MJIC / FMJIC SVL 90°	0.40	6500-8
2	2	11P87	HOSE ASS'Y 1/2 H.P. x 243 1/2	9.60	
3	ONE	11P83	HYD ADP, MJIC / ORB STR	0.40	6400-8-12
4	ONE	11P84	HYD ADP, MJIC / ORB 90°	0.40	6801-8-12
5	2	11P89	HYD ADP, MJIC / ORB STR	0.40	6400-8-6
				21.20	TOTAL



U.S.A. LTD.

HYDRAULIC SUB-ASSEMBLY

STABILIZER CIRCUIT

90H83



1800 NE Broadway Avenue, Des Moines, Iowa, U.S.A. 50313-2644
Phone: (515) 266-3042 • Fax: (515) 313-4426 • Toll Free: (888) 767-8000
E-Mail: sales@swaploader.net • Web Site: www.swaploader.com